

## Installation and Operating Manual

(Translation of the original installation and operating manual)

TRI...

TR...

## Turbo Coupling with Constant Fill and Pulley

including design as per ATEX directives:

Directive 94/9/EC (valid until April 19, 2016), Directive 2014/34/EU (valid from April 20, 2016)

Version 5 , 2016-01-11

3626-011200 en, Protection Class 0: public

Serial No. <sup>1)</sup>		
Coupling type <sup>2)</sup>		
Year of manufacture		
Mass (weight)		kg
Power transmission		kW
Input speed		rpm
Operating fluid	<input type="checkbox"/> mineral oil <input type="checkbox"/> water: Please contact Voith <input type="checkbox"/>	
Filling volume		dm <sup>3</sup> (liters)
Number of screws z <sup>3)</sup>		
Nominal response temperature of fusible plugs		°C
Pulley	Diameter: Profile: Number of grooves:	mm
Sound pressure level L <sub>PA,1m</sub>		dB
Installation position	<input type="checkbox"/> horizontal <input type="checkbox"/> vertical	
Drive via	<input type="checkbox"/> outer wheel <input type="checkbox"/> inner wheel	

1) Please indicate the serial number in any correspondence (→ Chapter 18).

2) T...: oil / TW...: water.

3) Determine and record the number of screws z (→ Chapter 10.1).

Please consult Voith Turbo in case that the data on the cover sheet are incomplete.

## Contact

Voith Turbo GmbH & Co. KG  
Division Mining & Metals  
Voithstr. 1  
74564 Crailsheim, GERMANY  
Tel. + 49 7951 32 409  
Fax + 49 7951 32 480  
startup.components@voith.com  
www.voith.com/fluid-couplings

3626-011200 en

This document describes the state of design of the product at the time of the editorial deadline on 2016-01-11.

Copyright © by  
Voith Turbo GmbH & Co. KG.

This document is protected by copyright. It must not be translated, duplicated (mechanically or electronically) in whole or in part, nor passed on to third parties without the publisher's written approval.

# Contents

<b>1</b>	<b>Voith Turbo Coupling with Constant Fill</b>	<b>7</b>
<b>1.1</b>	<b>Function</b>	<b>7</b>
<b>1.2</b>	<b>Type designation</b>	<b>9</b>
<b>1.3</b>	<b>Constructional examples</b>	<b>10</b>
<b>2</b>	<b>Technical data</b>	<b>12</b>
<b>3</b>	<b>Tightening torques</b>	<b>14</b>
<b>3.1</b>	<b>Fixing bolts</b>	<b>15</b>
<b>3.2</b>	<b>Fusible plugs, filler plugs, sight glasses, blind- and nozzle screws</b>	<b>15</b>
<b>3.3</b>	<b>Fastening screws</b>	<b>16</b>
<b>4</b>	<b>Declarations of Manufacturer</b>	<b>17</b>
<b>4.1</b>	<b>Declaration regarding assemblies and components</b>	<b>17</b>
<b>4.2</b>	<b>Conformity Declaration</b>	<b>18</b>
<b>5</b>	<b>User information</b>	<b>19</b>
<b>6</b>	<b>Safety</b>	<b>21</b>
<b>6.1</b>	<b>Safety information</b>	<b>21</b>
6.1.1	Structure of safety information	21
6.1.2	Definition of safety symbols	22
<b>6.2</b>	<b>Intended use</b>	<b>22</b>
<b>6.3</b>	<b>Unintended use</b>	<b>23</b>
<b>6.4</b>	<b>Structural modifications</b>	<b>23</b>
<b>6.5</b>	<b>General information as to dangerous situations</b>	<b>23</b>
<b>6.6</b>	<b>Remaining risks</b>	<b>28</b>
<b>6.7</b>	<b>What to do in case of accidents</b>	<b>28</b>
<b>6.8</b>	<b>Information with regard to operation</b>	<b>28</b>
<b>6.9</b>	<b>Qualification of staff</b>	<b>32</b>
<b>6.10</b>	<b>Product monitoring</b>	<b>32</b>

<b>7</b>	<b>Transport and Storage</b>	<b>33</b>
<hr/>		
7.1	As delivered condition	33
7.2	Scope of supply	33
7.3	Transport	33
7.4	Lifting	34
7.5	Storage / Packing / Preservation	39
<b>8</b>	<b>Installation and alignment</b>	<b>41</b>
<hr/>		
8.1	Tools	41
8.2	Preparation	42
8.2.1	Keys	43
8.3	<b>Turbo coupling installation</b>	<b>44</b>
8.3.1	Mounting	44
8.3.2	Mounting device	47
8.4	<b>Mounting of belts and belt tension</b>	<b>48</b>
8.4.1	Permissible radial force	48
8.5	<b>Alignment</b>	<b>51</b>
8.5.1	Alignment tolerances	51
8.5.2	Alignment	51
<b>9</b>	<b>Operating fluids</b>	<b>52</b>
<hr/>		
9.1	<b>Requirements to be fulfilled by the operating fluid ‘mineral oil’</b>	<b>53</b>
9.1.1	Usable operating fluids	53
9.1.2	Operating temperature frequently above 100 °C	53
9.1.3	Proposed operating fluids	54
9.2	<b>Proposed operating fluids for special requirements</b>	<b>55</b>
9.3	<b>Requirements to be fulfilled by the operating fluid ‘water’</b>	<b>56</b>
9.3.1	Usable operating fluids	56
<b>10</b>	<b>Filling, Filling Check and Draining</b>	<b>57</b>
<hr/>		
10.1	<b>Filling the turbo coupling</b>	<b>58</b>
10.1.1	How to fill turbo couplings installed in horizontal position, inclination < = 30°	58
10.1.2	How to fill turbo couplings installed in vertical position, inclination > 30°	60

<b>10.2</b>	<b>Level check</b>	<b>61</b>
10.2.1	Level check for turbo couplings installed in horizontal position	61
10.2.2	Level check for turbo couplings installed in vertical position	62
<b>10.3</b>	<b>Draining the turbo coupling</b>	<b>62</b>
10.3.1	Draining of turbo couplings without delay chamber installed in horizontal position	63
10.3.2	Draining of turbo couplings with delay chamber installed in horizontal position	63
10.3.3	How to drain turbo couplings installed in vertical position	64
<b>11</b>	<b>Commissioning</b>	<b>65</b>
<b>12</b>	<b>Operation</b>	<b>68</b>
<b>13</b>	<b>Maintenance, Servicing</b>	<b>69</b>
<b>13.1</b>	<b>Outside cleaning</b>	<b>72</b>
<b>13.2</b>	<b>Bearings</b>	<b>73</b>
13.2.1	Bearing lubrication when mineral oil is used as operating fluid	73
13.2.2	Bearing lubrication when water is used as operating fluid	73
13.2.3	Replacement of bearings / re-lubrication	73
<b>13.3</b>	<b>Belts</b>	<b>74</b>
<b>13.4</b>	<b>Fusible plugs</b>	<b>74</b>
13.4.1	Arrangement of fusible plugs	76
<b>14</b>	<b>Assembly Check, Commissioning and Maintenance Report</b>	<b>77</b>
<b>14.1</b>	<b>Assembly check report</b>	<b>78</b>
<b>14.2</b>	<b>Commissioning report</b>	<b>80</b>
<b>14.3</b>	<b>Maintenance report for general maintenance</b>	<b>82</b>
<b>15</b>	<b>Disassembly of Turbo Coupling</b>	<b>83</b>
<b>15.1</b>	<b>Preparation</b>	<b>83</b>
<b>15.2</b>	<b>Disassembly of basic type TR(I) turbo coupling</b>	<b>84</b>
15.2.1	Removal device	86
<b>15.3</b>	<b>Reassembly of turbo coupling</b>	<b>86</b>
<b>16</b>	<b>Disposal</b>	<b>87</b>
<b>17</b>	<b>Malfunctions – Remedial Actions</b>	<b>88</b>

---

<b>18</b>	<b>Queries, Orders Placed for Service Engineers and Spare Parts</b>	<b>91</b>
<b>19</b>	<b>Temperature monitoring</b>	<b>92</b>
<hr/>		
<b>19.1</b>	<b>MTS mechanical thermal switch unit for pre-warning</b>	<b>93</b>
<b>19.2</b>	<b>BTS non-contacting thermal switch unit</b>	<b>94</b>
19.2.1	BTS non-contacting thermal switch unit for pre-warning	94
19.2.2	BTS-Ex non-contacting thermal switch unit for limiting the maximum surface temperature	95
<b>19.3</b>	<b>BTM non-contacting thermal measuring device for pre-warning</b>	<b>96</b>
<b>20</b>	<b>Spare Parts Information</b>	<b>97</b>
<hr/>		
<b>20.1</b>	<b>Components overview - Voith turbo coupling 154 – 650</b>	<b>98</b>
<b>20.2</b>	<b>Spare parts for Voith turbo coupling 154 – 650</b>	<b>99</b>
<b>21</b>	<b>Representatives - Voith Turbo GmbH &amp; Co. KG</b>	<b>101</b>
<b>22</b>	<b>Index</b>	<b>106</b>

---

# 1 Voith Turbo Coupling with Constant Fill

## 1.1 Function




Fig. 1

The Voith turbo coupling is a hydrodynamic coupling working to the Föttinger principle. Its main elements consist of two blade wheels - the pump impeller and the turbine wheel - enclosed by a shell. Both wheels are provided with bearings relative to each other. The power is transmitted with hardly any wear, there is no mechanical contact between the power-transmitting parts. A constant amount of operating fluid is in the coupling.

The mechanical energy provided by the drive motor is converted into kinetic energy of the operating fluid in the connected pump impeller. In the turbine wheel, this kinetic energy is reconverted into mechanical energy.

Three conditions are to be considered with regard to the coupling function:




Fig. 2

**Standstill**

The whole operating fluid rests in the coupling.




Fig. 3

**Starting condition**

The pump impeller accelerates the operating fluid with increasing motor speed causing a circulating flow in the working chamber. The whole blade space of the turbine wheel is flooded, and the turbine wheel starts to move as a result of the kinetic energy of the fluid flow. The coupling characteristic curve determines the torque curve during start-up.




Fig. 4

**Nominal operation**

During nominal operation, only the torque required by the driven machine is transmitted. The low speed difference between pump impeller and turbine wheel (the so-called rated slip) results in a stationary flow condition in the coupling.



## 1.2 Type designation

For hydrodynamic couplings with constant fill, the type designation is determined as follows:

Type designation  
→ Cover sheet

1	2	3	4	5	6	7	8	9	10	11	12
---	---	---	---	---	---	---	---	---	----	----	----

Example: 562 TVVS RI03

562	T			VV		S	RI	03			
-----	---	--	--	----	--	---	----	----	--	--	--

1	<b>Coupling size (profile diameter in mm)</b> Possible sizes: 154, 206, 274, 366, 422, 487, 562, 650
2	<b>Number of hydrodynamic circuits</b> T: single-circuit coupling DT: double-circuit coupling
3	<b>Material</b> "no code letter": Silumin U: ferrous material
4	<b>Operating fluid</b> "no code letter": mineral oil W: Water (special case - please consult Voith).
5	<b>Delay chamber</b> "no code letter": without delay chamber V: with delay chamber VV: with enlarged delay chamber
6	<b>Draining of delay chamber</b> "no code letter": time-dependent draining without dynamic refill Y: with dynamic refill
7	<b>Shell</b> "no code letter" standard design S: designed as annular chamber
8	<b>Pulley bearings</b> R: pulley without bearings RI: pulley with bearings
9	<b>Design status</b> "no code letter": first design old: A, B, C, E, G, H, J new: 01, 02, 03, 04, 05, 06, 07, 08, 09, 10, ...
10	<b>Throttle plate</b> "no code letter": without throttle plate D: with throttle plate
11	<b>Design</b> "no code letter": standard design X: special constructional design Z: special hydrodynamic design
12	<b>Possible supplementary information in plain text</b>

### 1.3 Constructional examples

**Type TR (basic type):**




Fig. 5

**Type TRI (basic type):**




Fig. 6

**Type TVRI:**




Fig. 7

**Type TVVRI:**




Fig. 8

**Type TVVSRI:**




Fig. 9


**Type DTR / DTVR:**

Fig. 10


**Type DTRI / DTVRI:**

Fig. 11

## 2 Technical data



### Information required for use in potentially explosive atmospheres:


CE  marking:		
Ambient temperature, if deviating from -25 °C T <sub>a</sub> 40 °C		°C
max. surface temperature (T <sub>3</sub> = 200 °C, T <sub>4</sub> = 135 °C, or deviating)		°C
Temperature monitoring	<input type="checkbox"/> MTS <sup>1)</sup> for pre-warning	
	<input type="checkbox"/> BTS <sup>2)</sup> for pre-warning	
	<input type="checkbox"/> BTS-Ex <sup>2)</sup> for limitation of the max. surface temperature for Voith turbo couplings acc. to ATEX Directive. Maximum permissible temperature of turbo coupling when switching on the motor:	°C
Nominal response temperature of temperature monitoring		°C
Max. permissible filling volume <sup>3)</sup>		dm <sup>3</sup> (liters)
Overload (à Chapter 6.8), causing the thermal fuse (fusible plug/s and/or BTS-Ex) to respond, requires the power supply to be switched off after		s (sec)
An additional monitoring of the output speed is required to switch off the power supply before the fusible plugs respond.	<input type="checkbox"/> Yes <input type="checkbox"/> No	
After switching on the motor, monitoring of output speed has to begin after		s (sec)
Diameter of input (output) <sup>4)</sup>		mm
Diameter of pulley	(see cover sheet)	mm
For turbo couplings of type TRI only: Re-lubrication interval for the bearing underneath the pulley	Ask for a Voith service engineer	h
Replacement of ball and roller bearings after		h

Table 1

- 1) MTS: Mechanical thermal switch unit (→ Chapter 19.1).
- 2) BTS: Non-contacting thermal switch unit (→ Chapter 19.2).
- 3) Applies if filling volume is not indicated on the cover sheet.
- 4) Diameter and fit of hub or shaft to be joined by means of shaft-hub connection.

**Additional information/data required for use in potentially explosive atmospheres:**



### 3 Tightening torques

#### NOTICE

##### Damage to property

The turbo coupling may be damaged by incorrectly tightened screws.

- Tighten all screws using a torque-adjustable torque wrench!




Fig. 12

- 1) For arrangement and quantity, → Chapter 13.4.

### 3.1 Fixing bolts

Thread	Tightening torque in Nm						
	M8	M10	M12	M16	M20	M24	M30
Fixing bolt, item 0050	23	46	80	195	380	660	1350

Table 2

The tightening torques for fixing bolts apply to screws with property class 8.8 or higher (as per EN ISO 898-1), oil-moistened and relevant shaft journal material.

### 3.2 Fusible plugs, filler plugs, sight glasses, blind- and nozzle screws

Coupling size	Tightening torque in Nm (dimension of thread)				
	Fusible plug, item 0260, item 0395	Filler plug, item 0390	Blind screw, item 0265, item 0394	Sight glass, item 0396	Nozzle screw, item 0455, item 0456
154	8 (M8)	13 (M10)	8 (M8)	-	-
206	13 (M10)	20 (M12x1.5)	13 (M10)	-	-
274	13 (M10)	30 (M14x1.5)	13 (M10)	-	-
366 to 562	50 (M18x1.5)	80 (M24x1.5)	50 (M18x1.5)	50 (M18x1.5)	48 (M16x1.5)
650	144 (M24x1.5)	80 (M24x1.5)	144 (M24x1.5)	144 (M24x1.5)	48 (M16x1.5)

Table 3

### 3.3 Fastening screws

Coupling size and type	Tightening torque in Nm (dimension of thread)	
	Fasening screw, Item 0630	Fasening screw, item 0960
154 T	-	-
206 T	23 (M8)	18 (M8)
274 T	23 (M8)	62 (M12)
274 DT	46 (M10)	62 (M12)
366 T	46 (M10)	62 (M12)
422 T	46 (M10)	62 (M12)
487 T	80 (M12)	62 (M12)
562 T	80 (M12)	62 (M12)
650 T	195 (M16)	152 (M16)

Table 4

Screws with property class 8.8 or higher as per EN ISO 898-1 are used.



## 4 Declarations of Manufacturer

### 4.1 Declaration regarding assemblies and components

Since 29 December 2009, a new Machinery Directive 2006/42/EC has to be applied bindingly in the member states of the European Community.

Voith turbo couplings of Product Group "Start-up Components", as defined by the new Machinery Directive 2006/42/EC and the explanations of the guidelines published in December 2009 to implement the Machinery Directive, are neither "machines" nor "incomplete machinery", but rather assemblies or components.

As our products are no incomplete machinery, we do not issue a declaration of incorporation as per Machinery Directive 2006/42/EC.

An EC Declaration of Conformity must not be issued for these products either, nor CE marking be provided, unless specified by other EC directives or regulations.

Voith as certified company ensures that the basic safety and health requirements for their products are always met by internal quality management systems and by applying harmonized standards.

The technical documentation for Voith products is so comprehensive that they may be installed reliably into machinery or incomplete machinery. Safe operation of the complete machinery with regard to Voith products is also ensured at a later date when observing this documentation.

Issued in	Crailsheim, Germany
On	January 10, 2014
Name of the undersigned	Mr. J. Hagedorn, General Manager - Start-up Components

## 4.2 Conformity Declaration

EC Conformity Declaration as per Directive 94/9/EC (valid until April 19, 2016),  
EU Conformity Declaration as per Directive 2014/34/EU (valid from April 20, 2016)

The manufacturer Voith Turbo GmbH & Co. KG,  
Voithstraße 1, 74564 Crailsheim / Germany

hereby declares that the machinery described below:

Designation TRI...  
TR...  
Turbo coupling with constant fill and pulley  
Serial number see shipping documents

complies with the provisions of the following harmonized standards in the version valid on the date of signature:

EN ISO 12100-1 / -2	Safety of machinery - basic concepts and general principles for design Part 1: Terminology, methodology Part 2: Technical principles
EN 1127-1 / -2	Explosive atmospheres, explosion prevention, basic concepts and methodology
EN 13463-1	Non-electrical equipment for use in potentially explosive atmospheres, Part 1: Basic method and requirements
EN 13463-5	Non-electrical equipment intended for use in potentially explosive atmospheres, Part 5: Protection by constructional safety 'c'
EN 13463-8	Non-electrical equipment for potentially explosive atmospheres, Part 8: Protection by liquid immersion "k"
EN 1710	Equipment and components intended for use in potentially explosive atmospheres in underground mines

as well as with the following European and national standards and technical specifications in the version valid on the date of signature:

TRBS 2153	Avoidance of ignition hazards resulting from electrostatic charging
-----------	---

Each modification by the customer on the parts supplied, invalidates the declaration.

Issued in	Crailsheim, Germany
On	November 25, 2015
Name of the undersigned	Mr. J. Hagedorn, General Manager - Start-up Components

## 5 User information

This manual will support you in using the turbo coupling with pulley in a safe, proper and economical way.

If you observe the information contained in this manual, you will

- increase the reliability and lifetime of the turbo coupling and installation,
- avoid any risks
- reduce repairs and downtimes.

This manual must

- always to be available at the machine jobsite
- be read and used by every person who transports the turbo coupling, works on the turbo coupling or commissions the same.

The turbo coupling has been manufactured according to the latest design standard and approved safety regulations. Nevertheless, the user's or third party's life may be endangered or the machine or other property impaired in case of improper handling or unintended use.

### **Spare parts:**

Spare parts must comply with the technical requirements determined by Voith. This is guaranteed when original spare parts are used.

Installation and/or use of non-original spare parts may negatively change the mechanical properties of the **Voith turbo coupling** and thus have an adverse impact on safety.

Voith is not liable for any damages resulting from the use of non-original spare parts.

Use only appropriate workshop equipment for maintenance. Professional maintenance and/or repair can only be guaranteed by the manufacturer or an authorized specialist workshop.

This manual has been issued with the utmost care. However, should you need any further information, please contact:

Voith Turbo GmbH & Co. KG  
Division Mining & Metals  
Voithstr. 1  
74564 Crailsheim, GERMANY  
Tel. +49 7951 32 409  
Fax +49 7951 32 480  
startup.components@voith.com  
[www.voith.com/fluid-couplings](http://www.voith.com/fluid-couplings)

© Voith Turbo 2016.

The distribution as well as the reproduction of this document and the utilization and communication of its contents are prohibited unless expressly permitted. Offenders will be held liable for the payment of damages. All rights reserved in case a patent is granted, or a utility model or design is registered.


Voith Turbo reserves the right for modifications.

# 6 Safety

## 6.1 Safety information

Safety information indicating the descriptions and symbols as described in the following are used in the operating manual.

### 6.1.1 Structure of safety information

 <b>DANGER WORD</b>
<p><b>Hazard consequences</b></p> <p>Source of hazard</p> <ul style="list-style-type: none"> <li>• Warding off of danger</li> </ul>

#### Danger word

The danger word divides the severity of the danger in several levels:




Danger word	Severity of danger
 DANGER	Death or serious injury (irreversible personal injury)
 WARNING	Death or serious injury possible
 CAUTION	Minor or moderate injury possible
NOTICE	Possibly damage to property of - the product - its environment
SAFETY INFORMATION	General applications details, useful information, safe job procedure and proper safety measures

Table 5

#### Hazard consequences

Hazard consequences indicate the kind of hazard.

#### Source of hazard

The source of hazard indicates the cause of hazard.

#### Warding off of danger

Warding off of danger describes the measures to be taken to ward off a danger

### 6.1.2 Definition of safety symbols


Symbol	Definition
	Danger of explosion Marking with the Ex-symbol indicates possible hazards which have to be observed for the use in potentially explosive atmospheres.

Table 6

### 6.2 Intended use

The turbo coupling with constant fill and pulley is provided to transmit the torque from the drive motor to the driven machine.

The **power** permitted during stationary operation at a specific **input speed** and a specific **coupling filling** (operating fluid and filling) is entered on the cover sheet of this manual. Any use beyond that is deemed unintended (→ Chapter 6.3 Unintended use).

Intended use also includes observing this installation and operating manual and complying with the inspection and maintenance conditions.

The manufacturer is not liable for any damages resulting from unintended use. The risk has to be borne solely by the user.



#### SAFETY INFORMATION

- If not indicated accordingly in → Chapter 2, it is not allowed to use this turbo coupling in potentially explosive atmospheres!
- Please check with reference to the marking whether the turbo coupling is approved for potentially explosive atmospheres.
- If the zonal classification changes, the operator has to check whether it is still allowed to operate the turbo coupling in that zone.

A marking according to ATEX Directive and EN13463 has been provided on the periphery of the turbo couplings. The marking specifies in what potentially explosive atmospheres and under what conditions the use is permitted.

Example:   II 2D c 180 C X

Industrial area in which during normal operation an explosive atmosphere may form occasionally in form of a cloud of combustible dust in the air. Mechanical explosion protection by constructional safety. Maximum surface temperature: 180 °C.

### 6.3 Unintended use

The power transmission permitted during stationary operation at a specific input speed and a specific coupling filling (operating fluid and quantity) is entered on the cover sheet of this manual.

Any use beyond that described herein, e.g. for higher powers, higher speeds, other operating fluids or operating conditions that have not been agreed upon, is deemed unintended.

Moreover, it is not permitted to use BTS-Ex non-contacting thermal switch units from third parties.

### 6.4 Structural modifications

#### **WARNING**

##### **Risk of personal injuries and damage to property**

Structural modifications not done properly on the turbo coupling may cause personal injury and damage to property.

- Modifications, attachments or conversions on the turbo coupling are only allowed with the approval of Voith Turbo GmbH & Co. KG, Crailsheim.

### 6.5 General information as to dangerous situations

**For all work performed on the turbo coupling, please observe the local regulations for the prevention of accidents!**

**Hazards while working on the turbo coupling:**


#### **WARNING**

##### **Risk of injury**

While working on the turbo coupling, there is the risk of injury through cutting, crushing, burns and cold burns in case of minus degrees.

- Never touch the turbo coupling without wearing protective gloves.
- Start to work on the turbo coupling only after it has cooled down to below 44 °C!
- Ensure that there is sufficient light, a sufficiently large working space and good ventilation when working on the turbo coupling.
- Switch off the unit in which the turbo coupling is installed and secure the switch against inadvertent switch-on.
- For all work performed on the turbo coupling ensure that both the drive motor and the driven machine have stopped running and that a re-start is absolutely impossible!

**Hot surfaces:**

 **WARNING**

**Risk of burning**  
The turbo coupling gets warm during operation.

- Please provide a guard for protection against contact with the turbo coupling!  
However, ventilation of the turbo coupling must not be impaired.


**NOTICE**

**Damage to property**  
Thermal distortion or tensions if the warm turbo coupling is cooled down by means of fluids.

- Never use fluids to cool down the turbo coupling!
- Let the turbo coupling cool down at ambient temperature.

**Rotating parts:**

Protective cover  
→ Chapter 11


 **WARNING**

**Entanglement hazard**  
Rotating parts, such as the turbo coupling itself and exposed shaft parts need to be protected by a protective cover against contact with and entry of loose parts.

- Never operate the turbo coupling without these protective covers.

**Noise:**

Sound pressure  
level  
→ Cover sheet

 **WARNING**

**Hearing loss, permanent impairment of hearing**  
The turbo coupling generates noise during operation. If the A-classified equivalent sound pressure level  $L_{PA, 1m}$  exceeds 80 dB(A), this may cause impairment of hearing!

- Wear ear protection.



**Electric shock:****DANGER****Electric shock**

On account of incorrectly mounted or incorrectly connected electrical components, and disconnected electric connections, persons could get an electric shock and be severely injured, possibly with fatal consequences.

Incorrectly mounted or incorrectly connected electrical components and disconnected electric connections may cause damages to the machine.

- A qualified electrician has to properly carry out the connection to the electric supply network considering the system voltage and the maximum power consumption!
- The system voltage has to be in conformity with the system voltage indicated on the nameplate!
- There has to be a corresponding electrical protection by a fuse on the network side!

**DANGER****Electrostatic processes**

Electrostatic charging may injure persons by an electric shock.

- Allow only a qualified electrician to install the equipment into which the turbo coupling is installed.
- Machine and electric installation are provided with grounding connections.

**Overspeed:****NOTICE****Damage to property**

Non-recognition of overspeed, wrong direction of rotation or parameters outside the tolerance due to incorrect programming, may destroy the turbo coupling.

- Check whether the entire system is equipped with a device which safely prevents overspeed (for example brake or backstop).
- For rated speed, → cover sheet..

This refers only to installations where overspeed (exceeding the rated speed) is possible.

**Extreme ambient temperatures:**

Ambient temperature  
→ Chapter 2



**WARNING**

**Risk of personal injuries and damage to property**

Extreme ambient temperatures may result in thermal overload of the turbo coupling, thus causing the fusible plugs to melt and seriously injure any persons in their immediate surroundings, and to cause damage to the turbo coupling.

- Observe the permissible ambient temperature.

Only when water is used as operating fluid

**NOTICE**

**Damage to property**

The turbo coupling may be damaged by frozen operating fluid.

- The ambient temperature must be above the freezing point of the operating fluid.
- Adhere to the temperature limits indicated (→ Chapter 6.8).

**Operating fluid which sprays off or leaks out:**



**WARNING**

**Risk of losing sight due to operating fluid spraying off, risk of burning**

In case of thermal overload of the turbo coupling, the fusible plugs respond. Operating fluid leaks out through these fusible plugs.

- Persons close to the turbo coupling must wear safety goggles.
- Please make sure that the spraying-off operating fluid cannot get in contact with persons.
- If the fusible plugs spray off, switch off the drive immediately.
- Electrical devices located near the coupling need to be splash-guarded.

 **WARNING****Fire hazard**

After the fusible plugs responded, spraying off oil may ignite on hot surfaces causing fire, as well as releasing toxic gases and vapor.

- Make sure that spraying off operating fluid cannot get into contact with hot machine parts, heaters, sparks or open flames.
- Immediately switch off the driving machine when the fusible plugs respond.
- Please pay attention to the information contained in the safety data sheets.

 **CAUTION****Danger of slipping**

Slipping hazard due to spraying off solder of fusible plugs and leaking out operating fluid.

- Please provide a catch pan of sufficient size.
- Immediately remove any leaking out solder and operating fluid.
- Please pay attention to the information contained in the safety data sheets.

**Checking the methane content before working on the turbo coupling:** **WARNING****Explosion hazard**

For turbo couplings with housings made of aluminum alloys and when the protective cover was removed, if the permissible methane content is exceeded, there is the risk of explosion.

- Before and during all work performed on the turbo coupling, check the methane content around the turbo coupling.
- Should this permissible limit value be exceeded, the work has to be stopped until the value is again below the limit value.



**Permissible limit  
values according to  
local regulations**

## 6.6 Remaining risks



### WARNING

#### **Risk of personal injuries and damage to property**

Improper use or incorrect operation may cause death, serious injuries or minor injuries as well as damage to property and the environment.

- Only persons who are sufficiently qualified, trained and authorized are allowed to work on or with the turbo coupling.
- Please observe the warnings and safety information.

## 6.7 What to do in case of accidents

### SAFETY INFORMATION

- In case of accidents, please observe the local regulations, the operating manuals and the operator's safety measures.

## 6.8 Information with regard to operation

### SAFETY INFORMATION

- If irregularities are found during operation, immediately switch off the drive unit.

### **Power transmission:**

The cover sheet of this manual indicates the possible power transmission at a specific input speed and a specific coupling filling (operating fluid and quantity).

These values describe a permissible working point for the stationary operation of the turbo coupling.

### NOTICE

#### **Damage to property**

Deviations from the permissible working point cause damage the turbo coupling.

- Voith Turbo's approval is required for a stationary operation of the turbo coupling at a different working point.

**Operating fluid:****NOTICE****Damage to property**

Too little filling results in thermal overload of the turbo coupling, and in case of too much filling, the turbo coupling may be damaged by internal pressure.

- Operate the turbo coupling only with the filling quantity stated on the cover sheet of this manual.
- Use only the operating fluid indicated on the cover sheet of this manual.

**Heating up during start-up:****NOTICE****Damage to property**

During start-up, the turbo coupling heats up more than during stationary operation due to the increased slip.

- Please provide sufficient intervals between start-ups to avoid thermal overload.

**Starting characteristic of turbo couplings with delay chamber:**

On start-up, the operating fluid flows from the delay chamber into the turbo coupling working chamber. On standstill, the operating fluid returns into the delay chamber. Please provide sufficient intervals (a few minutes) between the starts to get a correct starting characteristic.



**Coupling temperature:**

**WARNING**

**Explosion hazard**

Explosion hazard due to high temperature of turbo coupling.

- Make sure that the air surrounding the turbo coupling does not exceed the permissible value.

Technical data  
→ Chapter 2 and  
ordering documents

**NOTICE**

**Damage due to under temperature**

The turbo coupling may be damaged by under temperature.

- Please consult Voith Turbo if the turbo coupling shall be used at ambient temperatures
  - below -25 °C for operating fluid 'oil'
  - below 1 °C for operating fluid 'water'

**NOTICE**

**Damage due to overheating**

Overheating (nominal temperature is exceeded) may damage the turbo coupling.

- Provide sufficient ventilation / aeration of the turbo coupling.

**Fusible plugs:**

The fusible plugs protect the turbo coupling against damage due to thermal overload.

Technical data  
→ Chapter 2

**NOTICE**

**Damage to property**

The turbo coupling will be damaged if operation is continued after a fusible plug responded.

- Switch off the drive motor immediately on response of one of the fusible plugs!
- Use original fusible plugs only with the response temperature indicated on the → cover sheet of this operating manual.

**Monitoring devices:****NOTICE****Damage to property**

Damage to turbo coupling due to monitoring devices not ready for service.

- Check whether existing monitoring devices are in a state ready for service.
- Repair any defective monitoring device immediately.
- Never bypass safety devices.

**Monitoring devices**  
→ Chapter 19

**Blocking:****NOTICE****Damage to property**

Blocking of the driven machine may cause overheating of the turbo coupling and response of the fusible plugs thus endangering persons as well as the turbo coupling and environment.

- Immediately switch off the driving machine.

**Overload of turbo coupling:**

After the thermal fuse responded, switch off the power supply after the time required in → Chapter 2 at the latest.

In case of multi-motor drive, switch off the whole system!

If an additional monitoring of the overload is required, monitor the output speed.

If the output speed falls below the input speed by more than 10%, immediately switch off the power supply.

It is necessary to switch off the power supply as otherwise the permissible surface temperature indicated cannot be met.



**Permissible surface temperature,**  
→ Chapter 2

**NOTICE****Overload of turbo coupling**

The turbo coupling will be overloaded in cases where

- the driven machine blocks
- the driven machine is loaded excessively during nominal operation and/or during start-up.

Please consult Voith Turbo in case of unforeseeable turbo coupling overload.

## 6.9 Qualification of staff

Only qualified and authorized professional staff are allowed to perform work, such as transportation, storage, installation, electrical connection, commissioning, operation, maintenance, servicing and repair.

Qualified professional staff in the sense of this operating manual are persons who are familiar with transportation, storage, installation, electrical connection, commissioning, maintenance, servicing and repair and who have got the necessary qualifications relevant to their job performed. Qualification has to be ensured by performing training and giving instructions on the turbo coupling.

This staff must be trained, instructed and authorized to:

- operate and service machines in a professional manner in accordance with the technical safety standards.
- use lifting appliances, slings (ropes, chains, etc.) and lifting points in a professional manner.
- properly dispose of media and their components, e.g. lubricating grease.
- service and use safety devices in a manner that ensures compliance with safety standards.
- prevent accidents and provide first aid.

Staff to be trained may only perform work on the turbo coupling under the supervision of a qualified and authorized person.

The staff in charge of any work to be done on the coupling must

- be reliable,
- have the legal age,
- be trained, instructed and authorized with regard to the intended work.

## 6.10 Product monitoring

We are under legal obligation to keep the performance of our products under observation, even after shipment.

Therefore, please inform us about anything that might be of interest to us. For example:

- Change in operating data,
- experience gained with the machine,
- recurring problems,
- problems experienced with this installation and operating manual.

**Our address,  
→ Page 2**



## 7 Transport and Storage

### 7.1 As delivered condition

- The turbo coupling is delivered completely, with mounted pulley (if included in the scope of supply).
- The turbo coupling is not filled. If the scope of supply includes the operating fluid, it will be delivered in a separate container.
- Other accessories will be supplied as loose parts.

**Packaging**  
→ Chapter 7.5

### 7.2 Scope of supply

The turbo coupling will be supplied as indicated on the cover sheet.  
A set of fusible plugs is supplied as spare one.

Additional parts belonging to the scope of supply, such as connecting coupling, fusible plugs, temperature monitoring, mounting and removal device, etc. will be stated in the order confirmation.

### 7.3 Transport



#### WARNING

##### Explosion hazard

For turbo couplings with housings made of aluminum alloys, there can be the risk of explosion when being transported in / through explosive atmospheres.

- In potentially explosive atmospheres it is only allowed to transport the turbo coupling in suitable packing.
- This transport packing has to meet the same minimum requirements as the protective cover.



**Protective cover**  
→ Chapter 11



#### WARNING

##### Risk of injury

Falling parts may seriously injure or kill you.

- Secure the turbo coupling sufficiently.
- Pay attention to the center of gravity position.
- Use the provided lifting points.
- Use appropriate transportation means and slings (ropes, chains, etc.).

 **WARNING**

**Risk of crushing**

Incorrect handling of the turbo coupling may cause bruising of upper and lower limbs and seriously injure persons.

- Skilled staff only is allowed to carry out transportation!

## 7.4 Lifting

### Lifting appliances, load carrying attachments, lifting points

For weight of the Turbo coupling → cover sheet. Weights of over 100 kg will be stamped on the turbo coupling.

Observe the turbo coupling weight!

Lifting appliances (e.g. crane, high-lift truck), slings (ropes, chains, etc.) and lifting points (swivels, thread size as for item 0960, → Chapter 3.3) need to be

- checked and approved
- sufficiently dimensioned and in sound condition,
- and may only be operated by authorized and trained persons.

It is not allowed to use eyebolts!

Read the operating instructions for lifting appliances, slings (ropes, chains, etc.) and lifting points!

 **WARNING**

**Risk of injury**

Damaged load carrying attachments or those with insufficient carrying capacity may break under load, with the consequence of serious or even fatal injuries!

- Check the lifting appliances and load carrying attachments for
  - sufficient carrying capacity (for weight, → cover sheet).
  - sound condition.

### Fixing the turbo coupling

 **WARNING**

**Risk of injury**

Falling parts may seriously injure or kill you.

- Do not walk under suspended loads.

**NOTICE****Personal injury and damage to property**

Improper fixing and lifting of the turbo coupling may cause personal injury and damage to property

- It is only allowed to lift the turbo coupling at the lifting points provided for this purpose (see the following pictures).
  - When fastening and lifting the turbo coupling, do not damage the ribbing of the turbo coupling through lifting appliances or load carrying attachments.
  - Damaged ribs may result in unbalance of the turbo coupling, thus causing uneven running of the machine.
- 
- Screw suitable swivels (thread size as for item 0960, → Chapter 3.3) into the turbo coupling.  
Do not unscrew existing screws for this purpose; please use the threads provided.
  - Fix the slings (ropes, chains, etc.).



Fig. 13



**WARNING**

**Risk of injury**

Danger to life and risk of injury caused by falling load, tilting or sliding of the turbo coupling.

- Slings (ropes, chains, etc.) must not be slung around the turbo coupling for lifting.
- Always use at least 2 slings (ropes, chains, etc.) for fixing.
- Do not walk under suspended loads.
- Observe the general guidelines for the prevention of accidents.
- Secure the turbo coupling against tilting and sliding as long as it is not mounted between the driving and driven machine.

**Turning the turbo coupling**

- Screw suitable swivels (thread size as for item 0960, → Chapter 3.3) into the turbo coupling.  
Do not unscrew existing screws for this purpose; please use the threads provided.
- Fix the slings (ropes, chains, etc.).



Fig. 14

**WARNING****Risk of crushing**

Incorrect handling of the turbo coupling may cause bruising of upper and lower limbs and seriously injure persons.

- Always use at least 2 slings (ropes, chains, etc.) for fixing.
  - For turning, please use 2 slings (ropes, chains, etc.) on each side.
- 
- On the opposite side, screw suitable swivels (thread size as for item 0960, → Chapter 3.3) into the turbo coupling.  
Do not unscrew existing screws for this purpose; please use the threads provided.
  - Fix the turbo coupling to the second slings.




Fig. 15

- Align the turbo coupling horizontally using the two lifting appliances.



Fig. 16

- Carefully set the turbo coupling down on a wooden board / pallet, and secure it against tilting.  
The turbo coupling has been turned.

## 7.5 Storage / Packing / Preservation

### As delivered condition

The as delivered condition of the Voith Turbo Couplings depends on the mode of transport and the storage period:

Condition No. 1 represents the delivered standard, for deviations, → ordering documents.

Condition No.	- Transport - Admissible storage period	Packing / Measures taken
1	- Overland / air transport - Storage up to <b>6 months</b> indoors (building)	- Device to suit transportation - Weather protection provided by the means of transport - Packed in PE foil
2	- Sea transport - Storage up to <b>6 months</b> indoors (building)	- Device to suit transportation - Sharp edges protected - Shrink-wrapped in PE foil - Desiccant according to DIN 55473 / 55474 - Water-proof cardboard or wooden box/crate - Line the inside of the crate lid with sealed ribbed PE sheets (Akylux). Put PVC foil underneath at butt joints
3	- Sea transport - Storage up to <b>12 months</b> indoors (building)	- As for Condition No. 2 - Improved preservation
4	- Sea transport - Storage up to <b>24 months</b> indoors (building)	- As for Condition No. 2 - Shrink-wrapped in aluminum sandwich foil instead of PE foil

Table 7

### Opening of the packaging

Foils that have been opened for inspection upon receipt are to be re-closed airtight for further storage. Use a new desiccant, if necessary.

### Disposal of the packaging

Dispose of packaging material according to the local regulations.

Notes on disposal  
→ Chapter 16

### Extension of storage period

The allowable storage period may be extended maximal three times according to the following descriptions. To do so, it is necessary to check the packaging and to possibly replace it.

After replacing the desiccant, close the foil packings airtight.

### External preservation / re-preservation

Renew the external preservation according to the allowable storage period. Spray bright metal parts (hub bores, brake disks, etc.) with Houghton Ensis DWG2462.

**Internal preservation / re-preservation:**

Renew the internal preservation annually (for Condition No. 4: every 2 years). Wet the turbo coupling inside with an oil selected from the selection list.

**Selection list for internal preservation agents**

Producer	Designation
ARAL	Aral Oil KONIT SAE 20W-20
Mobil	Mobilarma 524 (SAE 30)
Houghton	Ensis Engine Oil 20
Wintershall	Wintershall Antikorrol 20W-20

The recommended operating fluids may also be used for preservation.

Table 8

**Turbo coupling on bearings or mounted (turnable)**

For re-preservation, fill the turbo coupling with oil above the axis of rotation center and rotate the turbo coupling input and output at least once.

**Turbo coupling mounted (not turnable)**

Fill the turbo coupling up to the upper fusible plug.

Then drain the oil and close the plug on the turbo coupling according to the specified procedure. The oil may remain in the turbo coupling for another scheduled re-preservation if it is ensured that prior to commissioning, the turbo coupling is filled with fresh oil (oil quantity according to design documents).

Protect the turbo coupling against weather and environmental influences if it is installed in a machine that is not set into operation. Renew the external re-preservation every 6 months, internal re-preservation once a year.

If necessary, clean the turbo coupling outside before performing re-preservation. Proceed for external and internal re-preservation as described above.

Outside cleaning  
 → Chapter 13.1

<b>NOTICE</b>
<p><b>Damage to property</b>                  Danger of frost</p> <ul style="list-style-type: none"> <li>• When storing turbo couplings of type "TW" below 1 °C, drain the water.</li> </ul>



## 8 Installation and alignment



### WARNING

#### Risk of injury

Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!

### 8.1 Tools



### WARNING

#### Explosion hazard

There is the risk of explosion when using unsuitable tools.

- When using or assembling an Ex-coupling, use only tools approved for application in potentially explosive atmospheres.
- Observe the locally applicable regulations.
- Avoid formation of sparks.



The following tools are required; check in detail with the assembly plan.

#### Tools:

Set of open-end wrenches  
Set of ring spanners  
Socket wrench box (containing hexagon spanners, ratchet, etc.)  
Set of Allan keys  
Screwdrivers  
Torque wrenches  
Hammer, rubber mallet  
Set of files  
Wire brush

Dimension of thread  
→ Chapter 3

#### Measuring equipment:

Caliper gauge  
External screw-type micrometer according to shaft diameter  
Inside micrometer according to hub diameter

#### Mounting auxiliaries:

Auxiliaries for alignment of motor and gearbox (fastening screws),  
e.g. shims for motor and gearbox pedestals (0.1 - 0.3 - 0.5 - 1.0 - 3.0mm).  
Grinding cloth, graining 100, 240.

For swivel sizes,  
→ Chapter 3.3,  
Item 0960

**Lifting appliances and load carrying attachments:**

Crane.

Two shackles with appropriate slings (ropes, chains, etc.) for lifting the coupling.

Observe the pictures → 8.3.1!

Adjustable chains or ropes with sufficient tensile strength (see individual weights).

**8.2 Preparation**

Weight of turbo coupling  
→ cover sheet.  
Weights of more than 100 kg are stamped on the turbo coupling.

- Prepare suitable tools and lifting appliances.
- Observe the turbo coupling weight.
- Check the shaft journals of drive motor and driven machine for true radial running.
- Check the length of fixing bolt if the length of the shaft journal, on which the turbo coupling is mounted, was changed or not indicated to Voith Turbo.
- Clean fitting surfaces on shaft journals and hubs using emery cloth.
- Degrease flanges which will be bolted.
- Clean all preserved surfaces.
- Slightly oil the threads of bolts.
- Apply a thin film of lubricant to the shaft journals.

**SAFETY INFORMATION**

Use a lubricant with the following characteristics:

- Operating temperature range: -20 °C...180 °C,
- Water- and wash-out-resistant
- Protection against fretting corrosion and corrosion

**Proposed lubricants:**

Producer	Designation	Note
Dow Corning	Molykote G-N Plus Paste Molykote G-Rapid Plus Paste Molykote TP 42	
Fuchs	Gleitmo 815	
Liqui Moly	LM 48 Montagepaste	
Dow Corning	Molykote D 321 R Anti-Friction Coating	<b>Hazardous substance!</b> Observe the data sheet for hazardous substances!
Castrol Optimol	Molub-Alloy Paste White T Molub-Alloy Paste MP 3	

Table 9

## 8.2.1 Keys

### Requirement

Keys must

- have sufficient back clearance,
- be axially fixed and
- move easily in the grooves.

### Marking

When using a shaft-hub connection with key, the hub is marked at the face side according to DIN ISO 8821:

- H: Half-key convention
- F: Full-key convention

This mark should comply with the mark on the shaft.

### Inserting keys

#### SAFETY INFORMATION

Remove the key to avoid an unbalance in case of a shaft-hub connection with:

- one key
- balancing according to half-key convention
- and if the key is longer than the hub.

- For coupling hubs with a key or half-key convention, a compensation groove can be provided opposite for balancing of unbalance.
- For coupling hubs with a key and full-key convention, an identical compensation groove is provided opposite for balancing of unbalance.
- Clean the keyway.
- Insert the key straight into the keyway.
- Do not cant the key.
- If necessary, secure the inserted key against falling out.

## 8.3 Turbo coupling installation

### Inner wheel drive:

The turbo coupling is mounted on the drive motor shaft, and then the turbo coupling pulley is coupled through belts with the pulley of the driven machine.

### Outer wheel drive (special case):

The turbo coupling is mounted on the driven machine shaft, and then the turbo coupling pulley is coupled through belts with the pulley of the drive motor.

### 8.3.1 Mounting

Qualification  
→ Chapter 6.9



#### WARNING

##### Risk of crushing, injuries by cuts

During mounting and assembly, manual turning and positioning the turbo coupling, persons could bruise fingers or cut themselves on sharp edges thus getting seriously injured!

- Sufficiently qualified, instructed and authorized persons only are allowed to mount the turbo coupling!
- Proceed carefully.

#### NOTICE

##### Damage to property

The use of unsuitable working means or methods may cause damage to property.

- Only use tools suitable for mounting:
  - Mounting and removal device (from coupling size 274) available as accessory
- For mounting, **do not** use:
  - hammers
  - welding torches
  - pressure plates



#### SAFETY INFORMATION

##### Record the mounting process

For use in areas with potentially explosive atmosphere, it is mandatory to record the mounting process of the turbo coupling.

We recommend recording the process also for all other applications.

- For required records, → Chapter 14.

For turbo couplings using water as operating fluid, the hub bore is provided with a solid film lubricant. The lubricant must not be removed!

**For operating fluid  
'water' only**




Fig. 17

- Fix the turbo coupling to a suitable lifting appliance.



### WARNING

#### Risk of burning

The surface is hot due to getting warm.

- Do not touch the hub.

- Warm up carefully the hub to approx. 80 °C (facilitates mounting).
- Mount the turbo coupling on the relevant shaft journal.
- Insert the supplied holding disk:
  - For couplings **up to size 274** remove the circlip (item 0046) before inserting the holding disk, and then re-insert it.
  - For couplings **from size 366**, secure the holding disk against twisting by means of a roll pin (item 0070).
- Depending on the design of the shaft, ensure that the coupling hub is in contact with the shaft collar or the end face of shaft journal.

#### Coupling sizes 154 and 206:

- Insert a suitable and slightly oiled threaded rod in the shaft of the relevant machine.
- Mount the coupling on the shaft journal using a nut and a spacer tube.

Mounting device  
→ Chapter 8.3.2

**Coupling size 274 to 650:**

- Slightly oil the mounting spindle.
- Mount the coupling on the shaft journal using the mounting spindle, the spacer tube and the holding disk.




Fig. 18

Tightening torque  
→ Chapter 3.1

- Check the holding disk for proper seat.
- Put the locking plate and/or lock washer underneath the fixing bolt and tighten with the specified tightening torque.
- Secure the fixing bolt with the locking plate, if necessary.




Fig. 19

1) Lock washer up to coupling size 274

### 8.3.2 Mounting device

Mounting device for basic type TR or TRI turbo couplings is available at Voith Turbo.




Fig. 20

- A: Mounting spindle
- B: Original holding disk
- C: Coupling hub
- L1: Total length
- L2: Length of spacer tube
- n: Dimension of mounting spindle thread
- SW1: Width across flats

Coupling size	L1 in mm	L2 in mm	n	SW1 in mm	Article No. of mounting spindle	Article No. of spacer tube
274	520	135	M10	17	TCR.10659840	TCR.10659880
			M12	19	TCR.10659850	TCR.10659890
			M16	24	TCR.10659860	TCR.10659900
			M20	30	TCR.10659870	TCR.10659910
366, 422, 487	780	190	M16	24	TCR.11110620	TCR.11054200
			M20	30	TCR.10457720	TCR.11054210
			M24	36	TCR.10457730	TCR.10457920
			M30	46	TCR.10457740	TCR.11110770
562, 650	1150	245	M20	30	TCR.11110630	TCR.10457860
			M24	36	TCR.11110640	TCR.10457870
			M30	46	TCR.11071880	TCR.10457880

Table 10

## 8.4 Mounting of belts and belt tension

- Correct dimensioning of the belt drive depends on a number of factors and environmental conditions. Please observe the system and belt manufacturer's instructions!
- Please observe the system and belt manufacturer's instructions regarding mounting of belts and adjustment of belt tension.
- Belts must neither slip on startup nor during continuous operation.
- The pulleys must be in alignment during operation. Pulleys which are not in alignment may reduce the lifetime of the belts.
- Replace belts in sets.

### NOTICE

#### Damage to property

For turbo couplings with pulleys that have no bearings (type "TR"), please observe the radial load acting on the coupling caused by the belt tension.

- It is vital to consult Voith Turbo to determine the effective diameter of the pulley as it depends on the power and speed.

- Clean the pulley grooves. The grooves must be free from burrs, grease and other impurities.
- Check the alignment of the pulleys.
- Adjust the center distance of the pulleys so that the belts can be mounted without exerting any excessive force.
- Put the belts individually on the pulleys.
- Pretension the belts properly (→ Chapter 8.4.1).
- Check the alignment of the pulleys (→ Chapter 8.5).
- Operate the system for some time, and pay attention to irregularities (noise, vibrations, excessive heating of belts, etc.).
- Then check the pretension of the belts.

Commissioning  
→ Chapter 11

### 8.4.1 Permissible radial force

Permissible radial force  $F_r$  caused by the belt drive as a function of the lever arm  $h$ .

Basis: nominal lifetime  $L_{10h} = 25000$  h.

When the radial force indicated in the following diagrams is reduced by approx. 20%, the bearing lifetime increases to  $L_{10h} = 50000$  h.



**SAFETY INFORMATION**

The permissible radial force only applies to the turbo coupling. Reaction forces on adjacent components have to be regarded separately.

The lever arm  $h$  is defined as distance between the connection of bearing cover / pulley and the load application point in the (V-belt) pulley center; see the following illustration.




Fig. 21

**NOTICE****Damage to property**

If the belt pull of the system is higher than the permissible radial forces (→ diagrams):

- Please consult Voith Turbo.

**Diagram for TR..., DTR... couplings**




Fig. 22

**Diagram for TRI..., DTRI... couplings**




Fig. 23

## 8.5 Alignment

### 8.5.1 Alignment tolerances



#### WARNING

##### Explosion hazard

Explosion hazard due to damage to the material caused by excessive misalignments.

- Please observe the system and belt manufacturer's instructions!
- Pulleys which are not in alignment may reduce the lifetime of the system and the belts.
- In particular, observe any displacements due to changes in temperature.



#### SAFETY INFORMATION

##### Misalignments

The smaller the radial and angular displacement between turbo coupling and shaft journal

- the higher the lifetime and reliability of the machine.
- the smoother the operation.

### 8.5.2 Alignment

For alignment, support the motor feet using shims or foil sheets. It is advantageous to use claws for the adjusting screws on the foundation for lateral movement of the drive unit.

- Mount the turbo coupling.
- Align the input and output shafts with each other. The pulleys must be in alignment.
- Securely fix the motor and gearbox (input and output unit) to the foundation.  
**Stability depends on the whole unit and has to be guaranteed!**
- Tighten all screws.
- Check the alignment, and correct, if necessary.
- Fill in the assembly check report.

Protocols/reports  
→ Chapter 14

## 9 Operating fluids



### **WARNING**

#### **Risk of injury**

Hot operating fluid could spray off from defective components or fusible plugs, seriously injuring persons!

- Maintain the turbo coupling regularly!
- Experts only are allowed to work on the turbo coupling!

### **NOTICE**

#### **Damage to property**

Use only the operating fluid for the turbo coupling which is indicated on the cover sheet!

- Unsuitable operating fluids may damage the turbo coupling permanently!
- Consult Voith Turbo if you want to use an operating fluid not mentioned.

### **NOTICE**

#### **Environmental pollution**

Operating fluids are detrimental to health and may pollute the environment.

- Dispose of used operating fluid via an authorized collecting station in accordance with the national statutory provisions.
- Make sure that no operating fluid gets into the ground or water!


### **SAFETY INFORMATION**

The values mentioned for the pour point, flash and fire point are approximate values and data originating from the oil suppliers. These may vary and Voith Turbo does not assume any warranty!

Country-specific production of the basic oil may result in different values.

- We recommend comparing the data with our specifications at any rate.
- In case of deviations, we urgently recommend consulting the respective oil producer.

## 9.1 Requirements to be fulfilled by the operating fluid 'mineral oil'

Requirement to	
Viscosity class	ISO VG 32 nach DIN ISO 3448 *)
Viscosity on start-up	less than 15000 mm <sup>2</sup> /s (cSt)
Pour point	4 °C below the minimum ambient temperature or lower
Flash point	greater than 180 °C and at least 40 °C above the nominal response temperature of the fusible plugs
Resistance to aging	aging-resistant refined product
Cleanliness grade	Minimum requirements: 21/19/16 acc. to ISO 4406
Sealing compatibility	NBR (Nitril-Butadien caoutchouc) and FPM/FKM (fluor caoutchouc)
Fire point 	at least 50 °C above the max. surface temperature (→ Chapter 2)



\*) In special cases, ISO VG 10 - 46 can be used

### Advantageous additional qualities

Check for	Abrasion of rolling elements	< 30 mg
FE 8: D7,5 / 80-80	Abrasion of cage	<100 mg

### 9.1.1 Usable operating fluids

- Hydraulic oils HLP 32 to DIN 51524, Part 2 \*)
- Lubricating oils CLP 32 to DIN 51517, Part 3
- Steam turbine oils LTD 32 to DIN 51515, Part 1 \*)
- HD engine oils SAE 10 W
- ATF type A Suffix A (TASA) and type Dexron II, IID, IIE, III, MERCON
- M 891205 and M 921253

\*) In special cases, ISO VG 10 - 46 can be used

### 9.1.2 Operating temperature frequently above 100 °C

FPM/FKM is recommended as sealing material; when selecting the mineral oil, ensure that it provides excellent oxidation resistance.

**This is ensured if original Voith sealings are used.**

### 9.1.3 Proposed operating fluids

Producer	Designation	Pour point in °C	Flash point in °C	Fire point in °C	Class	FE8 Test fulfilled
Addinol	Hydraulic oil HLP 32	-21	195	-	HLP	-
Agip	Agip Oso 32 Agip Blasias 32	-30 -29	204 215	260 265	HLP CLP	-
Avia	Avia Fluid RSL 32 Gear RSX 32 S	-27 -33	214 210	237 231	HLP CLP	-
Castrol	Alpha EP 32 Alpha VT 32 Hyspin ZZ 32 Hyspin AWS 32	-27 -42 -30 -27	218 234 216 200	250 252 238 -	CLP CLP HLP HLP	JA JA JA -
Cepsa	HIDROSIC HLP 32 EP 125	-24 -30	204 206	316 316	HLP HLP	- -
Exxon Mobil	DTE 24 Mobilfluid 125 Mobil SHC 524	-27 -30 -54	220 225 234	- - 234	HLP CLP/HLP HLP	- - -
Fuchs	Renolin MR10 Renolin B10	-30 -24	210 205	- -	HLP HLP	- -
Klüber	Lamora HLP 32	-18	200	-	HLP	-
Kuwait Petroleum	Q8 Haydn 32 Q8 Holst 32	-30 -30	208 208	232 234	HLP HLP	- -
Ravenol	Hydr. oil TS32	-24	220	-	HLP	-
Shell	Tegula V32 Tellus S3 M 32 Tellus S4 ME 32	-33 -39 -54	211 236 240	- - -	HLP HLP HLP	JA - -
SRS – Salzbergen	Wintershall Wiolan HS 32 Wintershall Wiolan HF 32	-24 -27	220 200	240 240	HLP HLP	- JA
Texaco	Rando HD 32	-30	196	246	HLP	-
Total	Azolla ZS 32 Azolla VTR 32 Preslia GT	-27 -36 -15	210 230 225	220 - -	HLP CLPD LTD	- JA JA

Table 11

The above oil list is a recommendation and does not claim to be complete.

## 9.2 Proposed operating fluids for special requirements

### Operating fluid suitable for the use in the food industry

Producer	Designation	Pour point in °C	Flash point in °C	Class
Klüber	Summit HySyn FG 32	-45	>230	HLP

Table 12

Note: USDA H1-Registration satisfies the FDA requirements.

### High-flash point operating fluid

Producer	Designation	Pour point in °C	Flash point in °C	Fire point in °C	Class
Fuchs	Renosafe DU 46	-33	305	354	HFD-U

Table 13

Note: Fuchs Renosafe DU 46 is a high-flash point pressure fluid of viscosity class ISO VG 46 and contains neither chlorinated hydrocarbons nor phosphorus acid ester. The density of this fluid is lower than the density of water.

### Biodegradable operating fluid

Producer	Designation	Pour point in °C	Flash point in °C	Class
Fuchs	Plantosyn 3268	-36	230	HEES

Table 14

Note: Fuchs Plantosyn 3268 is a quickly biodegradable fluid of viscosity class ISO VG 46 corresponding to VDMA 24568. The water risk class is 1 and the density of this fluid is lower than the density of water.

### 9.3 Requirements to be fulfilled by the operating fluid 'water'

Requirement to	
Sealing compatibility	NBR (Nitril-Butadien caoutchouc)
ph value	5...8

The water used should

- to the greatest possible extent, be free from solid matters,
- contain only a low amount of salt,
- contain only a low concentration of other additives.

#### 9.3.1 Usable operating fluids

Normally, drinking water satisfies these requirements.



# 10 Filling, Filling Check and Draining

The quantity and type of operating fluid used substantially determines the performance of the turbo coupling.

- A too high quantity stresses the drive motor more on start-up and results in a higher stall torque.
- A too low quantity thermally loads the turbo coupling more and results in a lower stall torque.



## WARNING

### Risk of burning

The turbo coupling gets warm during operation.

- Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!
- Start to work on the turbo coupling only after it has cooled down to below 44 °C.



## CAUTION

### Danger to health

Operating fluids may cause irritations or inflammation if coming into contact with skin and mucous membranes.

- Please pay attention to the information contained in the safety data sheets.
- Please always wear safety goggles when working with the operating fluid!
- Should you get any operating fluid in your eyes, rinse them immediately using plenty of water and consult a physician without delay!
- After finishing work, carefully clean your hands with soap.



Impurities in the operating fluid cause higher wear on the coupling as well as damages to bearings so that explosion protection can no longer be guaranteed.

- Make sure that any containers, funnels, filling tubes, etc. used for filling the coupling, are clean.

### NOTICE

#### Damage to property

Non-compliance with specifications.

- Observe the quantity to be filled in that is indicated on the cover sheet of this operating manual.
- An overfilling is not permitted! This would lead to an undue high internal pressure in the coupling, which may destroy the coupling.
- An underfilling is not permitted! This will result in an improper operation of the coupling.
- Do not mix different types of operating fluids.
- Use only the operating fluid indicated on the cover sheet of this manual.
- Ensure that the original sealing rings used are in sound condition.

## 10.1 Filling the turbo coupling

### SAFETY INFORMATION

Turbo couplings are shipped unfilled.

- If operating fluid is included in the scope of supply, it is shipped in a separate container.

### 10.1.1 How to fill turbo couplings installed in horizontal position, inclination $\leq 30^\circ$

- Turbo couplings of sizes 154 – 274:  
Turn the turbo coupling until the filler plug (item 0390) is on top.
- Turbo couplings of sizes 366 – 650:  
Turn the turbo coupling until the filler plug (item 0390) that is closest to the sight glass (item 0396) is on top.
- Remove the filler plug (item 0390).
- Remove the top fusible plug (item 0260 or item 0395) for pressure compensation.

- Fill in the specified quantity of operating fluid (→ Chapter 9) through a fine strainer
  - mesh size  $\leq 25 \mu\text{m}$  for turbo couplings using oil and operating medium (type T...)
  - mesh size  $\leq 50 \mu\text{m}$  for turbo couplings using water as operating medium (type TW...)
 via the opening in the filler plug (item 0390).
- Tighten the filler plug (item 0390).
- If the coupling is provided with a sight glass (item 0396), tighten the fusible plug.

**Operating fluid and filling volume**  
→ Cover sheet

**Tightening torques**  
→ Chapter 3.2




Fig. 24

- Turn the turbo coupling until the operating fluid is just visible on the sight glass (if existing) or until the operating fluid can be seen on the (still) removed fusible plug, but is not yet leaking out.
- Determine the **number z** of the flange screws from the sight glass or fusible plug to the vertical axis. The first screw is the one which center line is in counting direction, **after** the intersection line through the sight glass or the fusible plug.
- For later filling level checks, record the **number z** of screws determined. In addition, mark the turbo coupling or the protective cover.
- Tighten the fusible plug (items 0260 or 0395).
- Check the coupling for leaks during a test run (with protective cover!).

**z =** \_\_\_\_\_

**Assembly check report**  
→ Chapter 14.1 or cover sheet  
**Tightening torques**  
→ Chapter 3.2

### 10.1.2 How to fill turbo couplings installed in vertical position, inclination > 30°




Fig. 25




Fig. 26

- Remove two screws being on top.
  - For an **upper pulley** up to coupling size 274 these are one blind screw and one filler plug, and from coupling size 366 these are two blind screws.
  - For a **lower pulley**, up to coupling size 274, these are one fusible plug and one filler plug, for coupling sizes 366 and 422 these are two blind screws, and from coupling size 487 two fusible plugs.
- Fill in the specified quantity of operating fluid (→ Chapter 9) through a fine strainer
  - mesh size ≤ 25 µm for turbo couplings using oil as operating medium (type T...)
  - Mesh size ≤ 50 µm for turbo couplings using water as operating medium (type TW...)
 via a screw hole. The second screw hole serves for pressure compensation.
- Re-close the screw holes on top using the screws (items 0260, 0265, 0394, or 0395). Rotate the turbo coupling with nominal speed for a short time to let the operating fluid **spread evenly**.
- Remove the screws being on top once again.
- Fit the level check device to the connection provided for this purpose. (→ schematic sketch above).
- Provide the level mark on the turbo coupling or protective cover for later level checks.
- Remove the level check device.
- Tighten slackened screws.  
 Tightening torque for the screw plug: **30 Nm** (M14x1.5).
- Check the coupling for leaks during a test run (with protective cover!).

The level check device is available at Voith Turbo as accessory for couplings from size 366.

Tightening torques  
 → Chapter 3.2

## 10.2 Level check

You will find the **filling volume** on the **cover sheet** of this operating manual.

### 10.2.1 Level check for turbo couplings installed in horizontal position

#### SAFETY INFORMATION

**From size 366**, turbo couplings are equipped with a sight glass in the outer wheel.

- The sight glass position is marked by an arrow.

- If no sight glass is provided, turn the turbo coupling until a fusible plug is on top. Then unscrew and remove this fusible plug.
- Turn the turbo coupling until the operating fluid is just visible on the sight glass or until the operating fluid can be seen on the removed fusible plug, but is not yet leaking out.
- Determine the **number z** of the flange screws from the sight glass or fusible plug to the vertical axis. The first screw is the one which center line is in counting direction, **after** the intersection line through the sight glass or the fusible plug.
- Compare the number of screws determined with the number of screws determined during filling. Please observe the marking provided additionally on the coupling or guard.
- Correct the quantity filled in, if necessary.
- Re-insert and tighten any removed fusible plug.
- Check the coupling for leaks during a test run (with protective cover!).

**Number z**  
→ Chapter 10.1

**Tightening torques**  
→ Chapter 3.2

## 10.2.2 Level check for turbo couplings installed in vertical position

### SAFETY INFORMATION

The level of turbo couplings **from size 366** is checked using a level check device. This level check device is available as accessory at Voith Turbo (→ schematic sketch, Chapter 10.1.2).

Turbo couplings **up to size 274** need to be drained to check the filling, and then be re-filled.

- Remove a screw being on top (fusible plug items, 0260 / 0395 or blind screw, items 0265 / 0394) for ventilation purposes.
- Remove the screw plug.
- Fit the level check device to the connection provided for this purpose.
- Compare the level with the marking that was provided when filling in.
- Correct the quantity filled in, if necessary.
- Remove the level check device.
- Tighten slackened screws.  
Tightening torque for the screw plug: **30 Nm** (M14x1.5).
- Check the coupling for leaks during a test run (with protective cover!).

Tightening torques  
→ Chapter 3.2

## 10.3 Draining the turbo coupling

### NOTICE

#### Environmental pollution

Improper disposal of operating fluid may cause damages to the environment!

- On disposal, please observe the applicable laws and the producer's or supplier's instructions.
- Provide suitable containers to collect the operating fluid.

Notes on disposal  
→ Chapter 16

### 10.3.1 Draining of turbo couplings without delay chamber installed in horizontal position

- Put a catch pan underneath.
- Turn the turbo coupling until one fusible plug is at the bottom.
- Remove this fusible plug.
- For aeration, remove one opposite filler of fusible plug.
- The operating fluid flows out from the turbo coupling.
- Wait until no more operating fluid comes out.
- Only use original seals.
- Re-tighten all screws.

**Tightening torques**  
→ Chapter 3.2

### 10.3.2 Draining of turbo couplings with delay chamber installed in horizontal position

- Put a catch pan underneath.
- Turn the turbo coupling until one fusible plug is at the bottom.
- Remove this fusible plug.
- For aeration, remove one opposite filler of fusible plug.
- The operating fluid flows out from the working chamber of the turbo coupling.
- Wait until no more operating fluid comes out.

#### **Coupling size 274:**

- Re-tighten the fusible and filler plugs.
- Switch on the drive motor for about half a minute to maximal one minute. The operating fluid in the delay chamber drains into the working chamber.
- Remove the fusible plug again.

#### **Coupling sizes 366 to 650:**

- Remove the nozzle screw (item 0455 / 0456).
- Turn the turbo coupling until the opening of the nozzle screw is at the bottom.
- The operating fluid flows out from the delay chamber of the turbo coupling.
- Wait until no more operating fluid comes out.
- Only use original seals.
- Tighten the nozzle screw.

Tightening torques  
→ Chapter 3.2

- Turn the turbo coupling until the opening of the fusible plug is at the bottom.
- The remaining operating fluid flows out from the working chamber of the turbo coupling.
- Wait until no more operating fluid comes out.
- Only use original seals.
- Re-tighten all screws.

### 10.3.3 How to drain turbo couplings installed in vertical position

#### SAFETY INFORMATION

On account of its design, the turbo coupling cannot completely drain when installed!

- Put a catch pan underneath.
- For aeration, remove one blind screw or fusible plug at the top of the coupling.

#### Up to coupling size 274:

- Remove one blind screw or fusible plug being at the bottom.

#### From coupling size 366:

- Remove the connection for the level check device.
- The operating fluids flows out from the turbo coupling.
- Wait until no more operating fluid comes out.
- Only use original seals.
- Tighten slackened screws.  
Tightening torque for the screw plug: **30 Nm** (M14x1.5).  
Tightening torque for the connection: **80 Nm** (M24x1.5).

Tightening torques  
→ Chapter 3.2



# 11 Commissioning



## WARNING

### Risk of injury

Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!

- A commissioning not performed properly could cause injury to persons, or harm to property and the environment!
- Experts only are allowed to perform commissioning, in particular, first starting of the turbo coupling!
- Secure the machine against unintentional switching on!

### Explosion hazard

- Please check with reference to the marking whether the turbo coupling is approved for use in potentially explosive atmospheres.
- Provide the turbo coupling with a protective cover (e.g. perforated sheet, size of holes approx. 10 – 12 mm). This protective cover has to
  - prevent intrusion of damaging foreign particles (stones, corrosive steels, etc.).
  - withstand expected impacts without any major damages, thus preventing contact of the turbo coupling with the protective cover. Especially turbo couplings with outer parts made of aluminum must not get in contact with corrosive steel or iron.
  - collect spraying solder of fusible plugs.
  - collect any operating fluid leaking out to prevent contact with parts (motor, belt) that might ignite or catch fire.
  - provide sufficient ventilation to maintain the maximum surface temperature specified.  
A perforated sheet with 65% hole cross section enclosing the coupling on all sides does not reduce the ventilation (consult Voith Turbo, if necessary).
  - guarantee safety distances to prevent hazard zones from being reached (DIN EN ISO 13857).

For constructional proposals for protective covers, please contact Voith Turbo.
- The turbo coupling is not equipped with insulated ball and roller bearings! The passage of current and stray currents may come from connected machines (e.g. VFD motor).
- In order to avoid electrostatic charging, it is not allowed to install the turbo coupling with an insulation on both sides.
- Provide an equipotential bonding between the input and output end.
- Provide machines on which overspeed is possible, with a device preventing reliably overspeed (e.g. brake or backstop).



Marking  
→ Chapter 6.2

 **WARNING**

**Hazard by being pulled in**

Slack clothing, long hair, necklaces, rings or loose parts may get caught and be drawn in or wound up causing serious injuries or damage to the turbo coupling and the environment.

- Only wear close-fitting clothes when working!
- Cover long hair with a hair net!
- Do not wear any jewelry (e.g. necklaces, rings, etc.)!
- Never operate the turbo coupling without protective cover!
- Fix a protective cover (e.g. plate with a hole size of about 10-12 mm) around the belt drive and exposed shaft parts.



Technical data  
→ Chapter 2

 **WARNING**

**Explosion hazard**

Explosion hazard due to frictional heat or overheating.

- Check the belt tension and readjust, if necessary.
- If you use a BTS-Ex to limit the maximum surface temperature, make sure not to exceed the maximum permissible temperature of the turbo coupling when switching on the motor.

**NOTICE**

**Damage to property**

Never operate the turbo coupling without operating fluid.

- On account of the type of bearings used for standard turbo couplings of sizes 366, 422, 487, 562, 650, at least one standstill within three months is required.
- On account of the type of bearings used for the standard turbo couplings of sizes 154, 206 and 274, at least one standstill per week is required.

### Information with regard to commissioning

- The turbo coupling may be used for any direction of rotation.
- The direction of rotation of the driven machine may be specified! The direction of rotation of the motor must be in accordance with the specified direction of rotation of the driven machine!
- If the motor is started with star/delta connection, switch over from star to delta after 2...5 seconds at the latest.
- In case of a multi-motor drive, you should determine the load of the individual motors. Great differences regarding motor load may be balanced by an appropriate adjustment of the respective coupling filling volumes. **However, do not exceed the maximum permissible coupling filling level!**

**Operating fluid and  
filling volume  
→ Cover sheet**

### Commissioning

- Perform all commissioning work according to the commissioning report.  
Pay special attention to:
  - a normal machine operation
  - normal noise
- Record the commissioning process.

**Commissioning  
report  
→ Chapter 14.2**

# 12 Operation



## **WARNING**

### **Risk of injury**

Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!

- An operation presupposes the successful commissioning according to → Chapter 11.

## **Information with regard to operation**

## **NOTICE**

### **Damage to property**

Never operate the turbo coupling without operating fluid.

- On account of the type of bearings used for standard turbo couplings of sizes 366, 422, 487, 562, 650, at least one standstill within three months is required.
- On account of the type of bearings used for the standard turbo couplings of sizes 154, 206 and 274, at least one standstill per week is required.

During normal operation, no operator actions on the turbo coupling are required.

Perform the necessary maintenance work time-/operating time-based according to → Chapter 13.

If malfunctions occur, eliminate such according to → Chapter 17.

## 13 Maintenance, Servicing

**Definition of the maintenance work described in the following (as per IEC 60079):**

**Maintenance and Servicing:** A combination of all activities conducted in order to maintain an object in a condition or to re-store it to such a condition which meets the requirements of the respective specification and ensures performance of the required functions.

**Inspection:** An activity involving the thorough examination of an object in order to provide a reliable statement as to the condition of said object, performed without disassembly or, if necessary, with only partial disassembly, supplemented by measures such as the taking of measurements.

**Visual inspection:** A visual inspection is an inspection in which visible defects, such as missing screws or bolts, are identified without the use of access equipment or tools.

**Close-up inspection:** An inspection in which, in addition to the areas covered by the visual inspection, defects such as loose bolts, that can only be detected by using access equipment, e.g. mobile stair steps (if required) and tools are identified. For close-up inspections, usually a housing does not need to be opened or the power to the equipment be cut off.

**Detailed inspection:** An inspection in which, in addition to the areas covered by the close-up inspection, defects such as loose connections, that can only be detected by opening housings and/or using tools and test equipment (if required) are identified.

**WARNING**

**Risk of injury**  
Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!

- Please always keep access paths free to the turbo coupling!

**Qualification**  
→ Chapter 6.9

- Skilled and authorized persons only are allowed to carry out maintenance and repair work! Qualification is ensured by performing training and giving instructions on the turbo coupling.
- Possible consequences of improper servicing and maintenance could be death, serious or minor injuries, damage to property and harm to the environment.
- Switch off the unit in which the turbo coupling is installed and secure the switch against inadvertent switch-on.
- For all work performed on the turbo coupling ensure that both the drive motor and the driven machine have stopped running and that a re-start is absolutely impossible!
- Components may only be replaced by original spare parts.

Re-mount all protective covers and safety devices in their original position immediately after completion of the servicing and maintenance work. Check them for proper functioning.

**Maintenance schedule:**

Time	Maintenance work
Routine inspection after 500 operating hours, every 3 months at the latest.	Inspect the machine for irregularities visual inspection: for leaks, noise, vibrations).  Check the foundation bolts of the machine, and if necessary, re-tighten them with the specified torque.
3 months after commissioning, at the latest, then every year	Check the electrical system for sound condition if temperature monitoring is required in Chapter 2 (detailed inspection).
When mineral oil is used as operating fluid: After every 15000 operating hours	- change the operating fluid or check it for aging and - determine the remaining service life (see records → Chapter 14)! Consult the operating fluid supplier with regard to the permissible values (see Chapters 9 and 10).

Time	Maintenance work
On response of a fusible plug	Replace all fusible plugs and change the operating fluid (→ Chapter 13.4). Check the operating conditions (→ Chapter 2). Check the devices provided for temperature monitoring (see Chapter 19: MTS, BTS(ex), BTM).
In case of leaks	On the occasion of an overhaul of the turbo coupling, have shaft sealing rings, sealing rings and flat seals replaced by skilled persons authorized by Voith.
In case of noise, vibrations	Have the cause determined and eliminated by skilled persons authorized by Voith.
In case of impurities	Cleaning (→ Chapter 13.1).
Upon the system and belt manufacturer's request	Check the belt drive (→ Chapter 13.3).

Table 15

- Carry out any maintenance work and routine inspections according to the report.
- Record the maintenance work carried out.

Report samples  
→ Chapter 14.3

**For explosion-proof turbo couplings, the following maintenance work needs to be carried out in addition:**



Maintenance intervals	Maintenance work
<b>In case of impurities or dusting:</b> Clean the turbo coupling when used in potentially explosive atmospheres in regular intervals. The intervals are specified by the operator according to the environmental impact to which the equipment is exposed on the jobsite, e.g. in case of a dust accumulation of approx. 0.2 ... 0.5 mm or more.	Cleaning (→ Chapter 13.1).
Maintenance interval → Chapter 2	- Replacement of ball and roller bearings (→ Chapter 13.2.3). - Re-lubricate the bearings underneath the pulleys (please call for a Voith service engineer).

Table 16



**WARNING**

**Explosion hazard**

Explosion hazard due to maintenance work not performed according to schedule. It is vital to carry out all maintenance work according to the schedule in order to guarantee proper operation within the meaning of explosion-protection.

- Immediately remove any combustible layers of dust on the turbo couplings.
- To ensure a good aeration of the turbo coupling, it is vital to check and clean the protective cover in regular intervals.
- If a fusible plug has responded, immediately cover or close the opening that occurred in order to prevent the ingress of combustible dust into the turbo coupling.

### 13.1 Outside cleaning

**NOTICE**

**Damage to property**

Damage to the turbo coupling due to an improper, unsuitable outside cleaning.

- Please ensure that the cleaning agent is compatible with the sealing materials used, NBR and FPM/FKM!
  - Do not use high-pressure cleaning equipment!
  - Be careful with gaskets. Do not apply a water and compressed-air jet.
- 
- Clean the turbo coupling with a grease solvent, as and when required.



## 13.2 Bearings

### 13.2.1 Bearing lubrication when mineral oil is used as operating fluid

Please observe the following in order to guarantee lubrication of the bearings:

#### NOTICE

##### Damage to property

Danger of bearing damage.

- On account of the type of bearings used for standard turbo couplings of sizes 366, 422, 487, 562 and 650, at least one standstill is required within three months.
- On account of the type of bearings used for the standard turbo couplings of sizes 154, 206 and 274, at least one standstill is required once a week.

#### SAFETY INFORMATION

##### Lifetime grease filling

- Turbo couplings can be provided with special bearings that allow continuous operation and contain a lifetime grease filling.

### 13.2.2 Bearing lubrication when water is used as operating fluid

The turbo coupling bearings are filled with lifetime grease when water is used as operating fluid. Re-lubrication is not necessary.

### 13.2.3 Replacement of bearings / re-lubrication

#### SAFETY INFORMATION

On the occasion of an overhaul of the turbo couplings, have the bearings replaced / re-lubricated by skilled persons authorized by Voith.



Replacement interval of ball and roller bearings  
→ Chapter 2

### 13.3 Belts

- Check the pretension of the belts in regular intervals.
- Replace any worn belts in sets.

#### SAFETY INFORMATION

Unusually quickly worn belts may be a sign of improper alignment!

### 13.4 Fusible plugs

Nominal response temperature of fusible plugs  
→ Cover sheet

- The fusible plugs protect the turbo coupling against damage due to thermal overload.
- When the nominal response temperature is reached, the solder core of the fusible plugs melts and the operating fluid leaks out.

Fusible plugs are identified by

- the engraved nominal response temperature in °C,
- a color coding:

Nominal response temperature	Color coding	Operating fluid Oil	Operating fluid Water
95 °C	without (tinned)	X	X
110 °C	yellow	X	X
125 °C	brown	X	-
140 °C	red	X	-
160 °C	green	X	-
180 °C	blue	X	-

Table 17

**SAFETY INFORMATION**

- Use only original fusible plugs SSS-X with the required nominal response temperature!
- Do not replace any fusible plugs by blind screws!
- Do not alter the arrangement of the fusible plugs.
- When water is used as operating fluid, only fusible plugs with a max. nominal response temperature of 110 °C are permitted!
- Never operate the turbo coupling without fusible plugs!

**Design**  
→ **Chapter 2**

**SAFETY INFORMATION****Switching elements, unbalance**

- There is a MTS and/or BTS switching element or a blind screw opposite the sight glass (position is marked by an arrow).
- Insert a weight-tolerated BTM blind screw opposite the BTM switching element. Do not insert the BTM switching element opposite a sight glass, blind screw or fusible plug having a lighter weight.

**On response of a fusible plug:**

- Replace all fusible plugs.
- Change the operating fluid.

**Tightening torques**  
→ **Chapter 3.2**

### 13.4.1 Arrangement of fusible plugs



Number and position of fusible plugs, blind screws and switching elements for inner wheel drive (outer wheel drive):

Coupling size and type	Shell (item 0190)			
	Fusible plug item 0260		Blind screw item 0265	
154 TR	-	(-)	-	(-)
154 DTR	-	(-)	-	(-)
206 TR / TRI	1	(1)	-	(-)
206 DTR / DTRI	-	(-)	-	(-)
274 TR	1	(1)	-	(-)
274 TRI	-	(-)	-	(1)
274 DTR / DTRI	-	(-)	-	(-)
366 TR / TRI	-	(-)	2	(2)
422 TRI	-	(-)	2	(2)
487 TRI	-	(-)	2	(2)
562 TRI	-	(-)	2	(2)
650 TRI	-	(-)	3	(3)

Coupling size and type	Outer wheel (item 0300)						
	Fusible plug item 0395		Blind screw item 0394		MTS, BTS, BTM <sup>3)</sup> - switching element <sup>2)</sup>		Sight glass <sup>4)</sup> item 0396
154 TR	1 <sup>1)</sup>	(1)	2	(-)	-	(-)	-
154 DTR	2 <sup>1)</sup>	(1)	2	(1)	1	(-)	-
206 TR / TRI	-	(-)	1	(1)	-	(-)	-
206 DTR / DTRI	2 <sup>1)</sup>	(1)	2	(1)	1	(-)	-
274 TR	-	(-)	1	(1)	-	(-)	-
274 TRI	1 <sup>1)</sup>	(1)	2	(-)	1	(-)	-
274 DTR / DTRI	2 <sup>1)</sup>	(1)	2	(1)	1	(-)	-
366 TR / TRI	2	(2)	3	(3)	1	(1)	1
422 TRI	4	(4)	3	(3)	1	(1)	1
487 TRI	4	(4)	3	(3)	1	(1)	1
562 TRI	4	(4)	3	(3)	1	(1)	1
650 TRI	2	(2)	3	(3)	1	(1)	1

Table 18

- 1) Radial arrangement
- 2) The MTS, BTS or BTM switching element is inserted instead of a blind screw.
- 3) The blind screw opposite the BTM has to be replaced by the counterweight (the BTM is not approved for use in potentially explosive atmospheres (→ Chapter 19.3).
- 4) Position is marked by an arrow.

# 14 Assembly Check, Commissioning and Maintenance Report



## WARNING

### Risk of injury

Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!

Document all assembly work performed in the assembly check report (→ Chapter 14.1).

Document the commissioning process in the commissioning report (→ Chapter 14.2).

## SAFETY INFORMATION

Document all **maintenance work** performed on the

- Turbo coupling  
in the maintenance report for the general maintenance (→ Chapter 14.3).



Use copies of the samples, if necessary.

## 14.1 Assembly check report

Confirm the check or performance of the work by an "X" and/or enter the respective values.

### Voith turbo coupling

Size / type (→ Chapter 18):

Serial No. (→ Chapter 18):

Turbo coupling approved for potentially explosive atmospheres      yes  / no

### Operating fluid of turbo coupling

Filling:  |

Producer:

Designation:

### Motor

Serial No.

Input speed  rpm

Rated power  kW

### Assembly work was performed:

Name:

Date:

Signature:

### Driven machine / gearbox

Serial No.

The following applies to the table below:

The shaft is the input shaft, if the coupling is driven by the shaft.

The shaft is the output shaft, if the coupling is driven by belts.

Mounting - check step	Explanations	Completion notice / dimensions
Check of fixing bolt length (item 0050)	→ order documents	<input type="checkbox"/>
Measurement of radial runout of the shaft.	Manufacturer's specification	Desired: [mm] ACTUAL: [mm]
Measurement of diameter of the pulley.	Chapter 2	Desired: [mm] ACTUAL: [mm]
Measurement of diameter <sup>1)</sup> of shaft.	Chapter 2	Desired: [mm] ACTUAL: [mm]
Check of back clearance of key (input side).	Chapter 8.2	<input type="checkbox"/>
Check of back clearance of key (output side).	Chapter 8.2	<input type="checkbox"/>
Key moves easily in the keyway of the input hub.	Chapter 8.2	<input type="checkbox"/>
Key moves easily in the keyway of the output hub	Chapter 8.2	<input type="checkbox"/>
Check of shaft-hub connection. Balancing method corresponds to DIN ISO 8821 and ISO 8821.	Chapter 8.2	Method applied: <input type="checkbox"/> Half-key convention <input type="checkbox"/> Full-key convention
Check of connection: bearing cover (item 0950) - pulley (item 0620).	Chapter 8.2	<input type="checkbox"/>
Check of alignment of pulley. Alignment tolerances comply with the specifications of the belt manufacturer.	Manufacturer's specifications	<input type="checkbox"/>
Cleaning of shaft and hub, and application of lubricant.	Chapter 8.2	<input type="checkbox"/>

1) Dimensions of shaft and/or hub to be connected by means of the shaft-hub connection.

Mounting - check step	Explanations	Completion notice / dimensions
Fixing bolt (item 0050) was tightened with torque.	Chapter 3.1	<input type="checkbox"/>
Foundation bolts were tightened.	Chapter 8.5.2	<input type="checkbox"/>
Mounting of coupling Screws (item 0960) were tightened.	Chapter 3.3	<input type="checkbox"/>
MTS / BTS / BTM (if required) Check of installation position according to operating manual.	Chapter 2 Chapter 19	<input type="checkbox"/>
MTS / BTS / BTM (if required) Check of electrical functioning.	Chapter 2 Chapter 19	<input type="checkbox"/>
A guard was mounted as recommended.	Chapter 11	<input type="checkbox"/>
Equipotential bonding between input and output was realized.	Chapter 11	<input type="checkbox"/>
Operating fluid was filled into the coupling.	Chapter 10	<input type="checkbox"/>
For <b>horizontally</b> installed turbo couplings only: Number of screws "z" for filling was determined.	Chapter 10.1	<b>z =</b> screws
For <b>vertically</b> installed turbo couplings only: Level check device was used. Fill level was marked on the coupling.	Chapter 10.1.2	<input type="checkbox"/>
Alignment of turbo coupling was checked.	Chapter 8.5.1	<input type="checkbox"/>
Radial running of motor shaft is OK		<input type="checkbox"/>
Displacements during operation (are to be indicated by the machine manufacturer): Observe displacements resulting from an increase in temperature or from mechanical movements. Enter only those values that change the above-ascertained alignment values.		

## 14.2 Commissioning report

Confirm the check or performance of the work by an "X" and/or enter the respective values.

**Voith turbo coupling**

Size / type (→ Chapter 18):

Serial No. (→ Chapter 18):

Turbo coupling  
 approved for potentially  
 explosive atmospheres      yes  / no

**Commissioning was performed by:**

after  Oper. hrs.

Name:

Date:

Signature:

Commissioning - check step	Explanations	Completion notice
<b>Checks prior to switching on the drive motor:</b>		
Assembly/mounting check steps were carried out. Fill in the assembly check report.	Chapter 14.1	<input type="checkbox"/>
Applies only to turbo couplings that are used in potentially explosive atmospheres: Check according to the marking whether the turbo coupling is approved for the use in potentially explosive atmospheres.	Chapter 6.2	<input type="checkbox"/>
For <b>horizontally</b> installed turbo couplings only: Check the filling level / determine the number of screws "Z" for filling.	Chapter 10.2	<input type="checkbox"/> / z =                  screws
For <b>vertically</b> installed turbo couplings only: Use the fill level check device. Compare the fill level with the previously made fill level marking.	Chapter 10.2.2	<input type="checkbox"/> / Difference =                  mm
Fix a guard over the turbo coupling (for design, → Chapter 11).	Chapter 11	<input type="checkbox"/>
Check whether the machine was earthed with a grounding cable (16mm <sup>2</sup> ).		<input type="checkbox"/>
Applies only to installations where overspeed is possible: Provide the unit with a device that reliably prevents overspeeds (e.g. brake or backstop).		<input type="checkbox"/>
Determine the next standstill of coupling for maintenance services.	Chapter 13	<input type="checkbox"/>
Check the belt tension, and readjust, if necessary. Observe the system and belt manufacturer's instructions.	Chapter 8.4 Chapter 8.4.1	
Applies only when a BTS-Ex is used as temperature monitoring system: Make sure that the maximum permissible turbo coupling temperature is not exceeded when switching on the motor!	Chapter 2	<input type="checkbox"/>
Check of foundation bolts.		<input type="checkbox"/>



Commissioning - check step	Explanations	Completion notice
<b>Checks during the test run:</b>		
Motor run-up is normal.		<input type="checkbox"/>
Turbo coupling is tight. Check of floor and environment for oil moistening, oil did not leak out.		<input type="checkbox"/>
Machine operation is normal.		<input type="checkbox"/>
Noises are normal.		<input type="checkbox"/>
<b>Checks after switching off the drive motor:</b>		
Turbo coupling is tight. Check of floor and environment for oil moistening, oil did not leak out.		<input type="checkbox"/>
<b>Check of switch units for temperature monitoring <sup>1)</sup>, if applicable:</b>		
Performance of a visual inspection.	<sup>1)</sup>	<input type="checkbox"/>
Removal of dust deposits.	<sup>1)</sup>	<input type="checkbox"/>
Check of electrical system.	<sup>1)</sup>	<input type="checkbox"/>

1) See separate operating manual / → Chapter 19

### 14.3 Maintenance report for general maintenance

Confirm the check or performance of the work by an "X" and/or enter the respective values.

**Voith turbo coupling**

Size / type (→ Chapter 18):

Serial No. (→ Chapter 18):

Turbo coupling approved for potentially explosive atmospheres      yes  / no

**The maintenance work was performed by:**

after  Oper. hrs.

Name:

Date:

Signature:

Maintenance - check step	Explanations	Completion notice
Check for irregularities (every <b>500 h</b> , every <b>3 months</b> at the latest)		
- Turbo coupling is tight. Check of floor and environment for oil moistening, oil did not leak out.		<input type="checkbox"/>
- Machine operation is normal.		<input type="checkbox"/>
- Noises are normal		<input type="checkbox"/>
- Check of protective cover.	Chapter 11	<input type="checkbox"/>
- Check of foundation bolts.		<input type="checkbox"/>
Check of switch units for temperature monitoring <sup>1)</sup> , if applicable (every <b>3 months</b> )		
- Performance of a visual inspection.	<sup>1)</sup>	<input type="checkbox"/>
- Removal of dust deposits.	<sup>1)</sup>	<input type="checkbox"/>
- Check of electrical system (after <b>3 months</b> , then <b>every year</b> ).	<sup>1)</sup>	<input type="checkbox"/>
Operating fluid (every <b>15000 h</b> )		
- Check of operating fluid.		<input type="checkbox"/>
- Determination of remaining operating time.		<input type="checkbox"/> /            hours
- Change of operating fluid.	Chapter 10	<input type="checkbox"/>
Ball and roller bearings (for the intervals, → Chapter 2)		
- Replacement of ball and roller bearings.	Chapter 13.2.3	<input type="checkbox"/>
- Re-lubrication of bearings underneath the pulley.	Ask for a Voith service engineer.	<input type="checkbox"/>
Cleaning of turbo coupling (after every contamination)		
- Cleaning was performed.	Chapter 13.1	<input type="checkbox"/>

1) See separate operating manual / → Chapter 19

# 15 Disassembly of Turbo Coupling

## WARNING

### Risk of injury

Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!

- Before beginning to work on the turbo coupling, switch off the main switch of the drive motor and secure it against being switched on!
- For all work performed on the turbo coupling ensure that both the drive motor and the driven machine have stopped running and that a re-start is absolutely impossible!

## 15.1 Preparation

- Prepare suitable tools and lifting appliances.  
Observe the turbo coupling weight!
- Remove the belts.

**Weight of turbo coupling**  
→ cover sheet.  
**Weights of more than 100 kg are stamped on the turbo coupling.**

## WARNING

### Risk of injury

Damaged load carrying attachments or those with insufficient carrying capacity may break under load, with the consequence of serious or even fatal injuries!

- Check the lifting appliances and load carrying attachments for
  - sufficient carrying capacity (for weight, → cover sheet),
  - sound condition.

## WARNING

### Risk of injury

Falling parts may seriously injure or kill you.

- Do not walk under suspended loads.

- Fix the turbo coupling to a suitable lifting appliance.

**Lifting appliances**  
→ Chapter 7.4

## 15.2 Disassembly of basic type TR(I) turbo coupling

### NOTICE

#### Damage to property

Turbo coupling may be damaged due to improper use of the removal device.

- It is not allowed to use an impact screwdriver to apply the torque.

Removal device  
→ Chapter 15.2.1

### SAFETY INFORMATION

From **size 274**,

- the use of a mounting and removal device is recommended and can be procured as accessory from Voith Turbo.
- For holding the motor shaft, we recommend using the **spanner wrench** (→ schematic sketch below) which is available as special accessory from Voith Turbo.




Fig. 27

- **Coupling sizes 154 and 206:**
  - Remove the fixing bolt.
  - Screw a suitable and slightly oiled screw into the internal thread of the holding disk and remove the turbo coupling.
  
- **Coupling size 274:**
  - Remove the circlip, fixing bolt and holding disk.
  - Put the threaded ring (item G), supplied together with the removal device, into the coupling hub.
  - Secure the threaded ring using the circlip.
  - Apply lubricant to the thread of the puller spindle.
  - Screw the puller spindle into the internal thread of the threaded ring.
  - Support the puller spindle by a substructure.
  - Remove the turbo coupling using the puller spindle.
  
- **Coupling sizes 366 to 650:**
  - Remove the fixing bolt and holding disk.
  - Screw the threaded ring (item G), supplied together with the removal device, into the coupling hub.
  - Apply lubricant to the thread of the puller spindle.
  - Screw the puller spindle into the internal thread of the threaded ring.
  - Support the puller spindle by a substructure.
  - Remove the turbo coupling using the puller spindle.

Lubricant  
→ Chapter 8.2

Lubricant  
→ Chapter 8.2

### 15.2.1 Removal device

Removal device available at Voith Turbo for turbo couplings of basic type TR(I):




Fig. 28

- A: Puller spindle
- C: Coupling hub
- G: Threaded ring
- L: Total length
- Q: Dimension of thread of puller spindle
- SW: Width across flats

Coupling sizes	L in mm	Q in inches	SW in mm	Article No. of puller spindle	Hub bore in mm
274	360	G ½	34	TCR.11947150	For hub bore Ø 22-26
274	360	G ¾	36	TCR.10657260	For hub bore > Ø 26
366	520	G 1	46	TCR.11071730	-
422	700	G 1 ¼	55	TCR.11071760	-
487	700	G 1 ¼	55	TCR.11071790	-
562	910	G 1 ½	60	TCR.11071800	-
650	910	G 1 ½	60	TCR.11071830	-

Table 19

### 15.3 Reassembly of turbo coupling

Procedure for reassembly of the turbo coupling is described in → Chapter 8.3.

# 16 Disposal

## Disposal of the packaging

Dispose of packaging material according to the local regulations.

## How to dispose of operating fluids

On disposal, please observe the applicable laws and the producer's or supplier's instructions.

## How to dispose of the turbo coupling

Clean the turbo coupling carefully to ensure a purity of material.

Dismantle the turbo coupling, if necessary.

Dispose of the turbo coupling according to the local regulations.

For special information on the disposal of the substances and materials used, please see the following table:

Material / substance	Kind of disposal		
	Reuse	Residual waste	Special waste
Metals	x	-	-
Cables	x	-	-
Seals	-	x	-
Plastics	x <sup>1)</sup>	(x)	-
Operating media	-	-	x <sup>1), 2)</sup>
Packaging	x	-	-

Table 20

- 1) If possible
- 2) Disposal according to the safety data sheet or the manufacturer's instructions

# 17 Malfunctions - Remedial Actions

**WARNING**

**Risk of injury**  
Please observe, in particular, → Chapter 6 (Safety) when working on the turbo coupling!

The following table is intended to help finding the cause of malfunctions or problems quickly and to take remedial action, if necessary.

Malfunction	Possible cause(s)	Remedial action	See
Starting behavior of driven machine is not as expected.	Turbo coupling is not filled with the correct quantity of operating fluid.	Check and correct the quantity filled in.	Chapter 10.1
	The operating conditions have changed.	Please consult Voith Turbo.	Chapter 18
Driven machine does not reach the specified speed.	Driven machine is blocked or overloaded.	Eliminate blocking or the cause of overload.	
	Turbo coupling is not filled with the correct quantity of operating fluid.	Check and correct the quantity filled in.	Chapter 10.1
	The belts are damaged and/or the belt tension is incorrect.	Replace the belts in sets and/or apply the correct tension to the belts.	Observe the belt manufacturer's instructions.
Drive motor does not reach normal operation within the expected time.	Changeover from star to delta too late.	Changeover from star to delta should be made after 2...5s at the latest.	
	Drive motor is electrically or mechanically not in order.	Have the drive motor checked by authorized personnel.	



<b>Malfunction</b>	<b>Possible cause(s)</b>	<b>Remedial action</b>	<b>See</b>
Operating fluid leaks out of the turbo coupling.	A fusible plug responded due to overload (excess temperature).	Clarify the cause for the overload. Replace <b>all</b> fusible plugs and change the operating fluid.	Chapter 13.4
	The turbo coupling is leaky.	Eliminate the leak, check, in particular, tightening torques and seal rings of fusible and filler plugs as well as sight glasses and, if necessary, check the switching element of the thermal switch unit. If the leak cannot be eliminated, please consult Voith Turbo.	Chapter 3  Chapter 18
An existing thermal monitoring unit (MTS, BTS or BTM) has responded.	The turbo coupling was overloaded.	Clarify the cause for the overload, and avoid another overload.  Check and correct the quantity filled in.	Chapter 19  Chapter 10.2
	Thermal monitoring unit (MTS, BTS or BTM) is defective.	Check the monitoring unit.	Chapter 19
Uneven running of the machine (increased vibration).	Foundation fixing is loose.	Retighten the foundation fixing. Align the machine.	
	The machine is not aligned.	Align the machine.	Chapter 8.5
	Machine is not balanced.	Clarify the cause and eliminate the unbalance.	
	The belts are damaged and/or the belt tension is incorrect.	Replace the belts in sets and/or apply the correct tension to the belts.	Observe the belt manufacturer's instructions.
	Bearings are damaged.	Eliminate the bearing damage; consult Voith Turbo in case of a bearing damage on the turbo coupling.	Chapter 18
	Loose screw connections.	Check the coupling components for damages, and replace the same, if necessary. Check the alignment of the machine. Tighten the screws and bolts with the specified tightening torque.	Chapter 3

<b>Malfunction</b>	<b>Possible cause(s)</b>	<b>Remedial action</b>	<b>See</b>
Premature wear of the belt drive.	Alignment error.	Eliminate the cause for alignment error. Re-align the machine. Check the belts for wear.	
	Impermissible temperatures.	Eliminate the cause for excessive temperature. Replace all belts. Re-align the machine, if necessary.	
	Contact with aggressive media.	Check the coupling components for damages, and replace the same, if necessary. Replace all belts. Re-align the machine, if necessary. Eliminate the cause for contact with aggressive media.	Chapter 8.5
	Excessive torque	Eliminate the cause for excessive torque. Check the filling level.	Chapter 10.2
Wear / fracture of pulleys / screws (item 0630 / bearing cover (item 0950) / bearing (item 0140)).	Belt drive is worn / coupling parts are worn.	Replace damaged coupling components. Re-align the machine. Shorten maintenance intervals.	Chapter 8.5
	Excessive torque	Check the coupling design. Please consult Voith Turbo. Install the new coupling. Re-align the machine.	Chapter 18

Please consult Voith Turbo (→ Chapter 18), in case of a malfunction which is not included in this table.


Table 21

# 18 Queries, Orders Placed for Service Engineers and Spare Parts

For

- Queries
- Ordering a service engineer
- Spare parts orders
- Commissionings

we need:



the **serial number** and **type designation** of the turbo coupling.

- You will find the serial number and type designation either on the outer wheel / coupling shell (A) or on the turbo coupling periphery (B).
- The serial number is stamped in with figure stamps.
- For turbo couplings, intended for the use in potentially explosive atmospheres, you will find the CE-Ex marking on the turbo coupling periphery.

Fig. 29

When placing an order for a **service engineer**, **commissioning** or a **service**, we need, in addition

- the turbo coupling installation site,
- the name and address of a contact person,
- details of the malfunction/problem occurred.

When placing a **spare parts order**, we need, in addition,

- the destination for the spare parts shipment.

Please contact the local Voith representative (outside business hours: the emergency hotline).

**Representatives**  
→ Chapter 21

## 19 Temperature monitoring



### SAFETY INFORMATION

The thermal switch units MTS and BTS can be used in potentially explosive atmospheres to monitor the temperature. The signals serve for pre-warning. The MTS or BTS do not limit the maximum surface temperature.

The BTS-Ex is available as safety device to limit the maximum surface temperature, and it can be used as thermal switch-off device.

Also in this case, it is not allowed to replace the existing fusible plugs by fusible plugs with different nominal response temperatures or by blind screws.

Never bypass safety devices!

### DANGER

#### Electric shock

Electric voltage may kill or severely injure you

- A qualified electrician has to properly carry out the connection to the electric supply network considering the system voltage and the maximum power consumption.
- The system voltage has to be in conformity with the system voltage indicated on the nameplate.
- There has to be a corresponding electrical protection by a fuse on the network side.

The temperature in the turbo coupling can be monitored by means of a limit switch or a temperature instrument.

The following systems are available as limit switch:

- a mechanical MTS system
- an electronic BTS system

These limit switches serve to monitor the temporarily permissible peak temperature, and to prevent a response of the fusible plugs provided the overload is eliminated promptly (e.g. by switching off the drive).

The BTM can be used as temperature measuring device. This way, not only the temporarily permissible peak temperature can be monitored, but also the nominal operation.

## 19.1 MTS mechanical thermal switch unit for pre-warning




Fig. 30

### Functioning:

On excess temperature, the switching element releases a pin. The pin activates a switch on coupling rotation. This signal, for example, may trip an alarm or switch off the drive motor. The switching element needs to be replaced.

**In case of inner wheel drive and blocking of driven machine, the function is no longer guaranteed!**

For the MTS, Operating Manual 3626-011800 is available at Voith Turbo. Or download it at [www.voith.com/fluid-couplings](http://www.voith.com/fluid-couplings).

The MTS is available for turbo couplings of all sizes.

For arrangement, see the table in → Chapter 13.4.1.

The switch is available in two designs:

- enclosed [protection IP 65],
- suitable for use in potentially explosive atmospheres  
type of protection:  $\text{Ex}$  II 2G EEx d IIC T6 (PTB 03 ATEX 1067 X).  
 $\text{Ex}$  II 2D IP65 T 80 C (PTB 03 ATEX 1067 X).

For the BTS,  
Operating Manual  
3626-011500 is  
available at Voith  
Turbo.  
Or download it at  
[www.voith.com/fluid-couplings](http://www.voith.com/fluid-couplings).

## 19.2 BTS non-contacting thermal switch unit

### 19.2.1 BTS non-contacting thermal switch unit for pre-warning




Fig. 31

#### Functioning:

On excess temperature, the switching element gives a specific signal to the initiator. This signal is transferred to an evaluator and may, for example,

- trigger an alarm
- or switch off the drive motor.

After the turbo coupling has cooled down, the switching element is again ready for service; it does not have to be replaced.

The BTS is provided for turbo couplings from **size 206**.

For arrangement, see the table in → Chapter 13.4.1.

Switching element and initiator are

- cast in plastic,
  - insensitive to dirt,
  - suitable for use in potentially explosive atmospheres
- type of protection:  $\text{Ex}$  II 2G EEx ia IIC T6 (PTB 00 ATEX 2048 X).  
 $\text{Ex}$  II 1D Ex iaD 20 T... C (ZELM 03 ATEX 0128 X).



#### SAFETY INFORMATION

As the control circuit of the evaluator is **not** intrinsically safe, provide an appropriate isolating switch amplifier between evaluator and initiator!


- Isolating switch amplifier type KFD2-SOT2-Ex2 (24 V DC)  
type of protection:  $\text{Ex}$  II (1) GD [EEx ia] IIC (PTB 00 ATEX 2035).
- Isolating switch amplifier type KFA6-SOT2-Ex2 (230 V AC)  
type of protection:  $\text{Ex}$  II (1) G [EEx ia] IIC (PTB 98 ATEX 2164).

## 19.2.2 BTS-Ex non-contacting thermal switch unit for limiting the maximum surface temperature



For the BTS-Ex, Operating Manual 3626-019600 is available at Voith Turbo.

Or download it at [www.voith.com/fluid-couplings](http://www.voith.com/fluid-couplings).



### Functioning:

On excess temperature, the switching element gives a specific signal to the initiator. This signal is sent to an isolating switch amplifier and has to enforce the switch-off of the drive motor.

Use a BTS-Ex approved by Voith for this application.

After the turbo coupling has cooled down, the switching element is again ready for service; it does not have to be replaced.

Fig. 32

The BTS-Ex is provided for turbo couplings from **size 366**.

For arrangement, see the table in → Chapter 13.4.1.

The BTS-Ex is provided for use in potentially explosive atmospheres as per ATEX Directive in Equipment Group II, Equipment Category 2G and 2D (Ex II 2GD).

### SAFETY INFORMATION

The BTS-Ex for limiting the maximum surface temperature is approved only in connection with the components supplied by Voith according to BTS-Ex operating manual.

Use of original Voith spare parts is imperative in case of a replacement demand.

The evaluator serves to transmit control commands from potentially explosive atmospheres into non-explosive areas and to safely isolate intrinsically safe and non-intrinsically safe circuits.

- Make sure not to exceed the maximum permissible temperature of the turbo coupling when switching on the motor.



Technical data  
→ Chapter 2

For the BTM, Operating Manual 3626-019800 is available at Voith Turbo. Or download it at [www.voith.com/fluid-couplings](http://www.voith.com/fluid-couplings)

### 19.3 BTM non-contacting thermal measuring device for pre-warning




Fig. 33

#### Functioning:

The temperature sensor permanently transmits a measuring signal to the antenna. This signal is sent to an evaluator with 4 channels.

The measured temperatures of every channel are indicated on the evaluator. In addition, the measured temperatures are output as 4-20 mA signals.

Furthermore, two relay outputs are available per measuring channel with switching thresholds (e.g. pre-warning, switch-off) adjustable via the keyboard on the evaluator.

The BTM is provided for turbo couplings from **size 366**.

For arrangement, see the table in → Chapter 13.4.1.



#### SAFETY INFORMATION

The BTM is not provided for use in potentially explosive areas as per ATEX Directive.



## 20 Spare Parts Information

### SAFETY INFORMATION

#### Variety of variants

Considering the great variety, please find in the following only the basic designs of turbo couplings with constant fill and pulley.

- Spare parts must comply with the technical requirements determined by Voith. This is guaranteed when original spare parts are used.  
Installation and/or use of non-original spare parts may negatively change the mechanical properties of the **Voith turbo couplings**, and may thus impair safety. Voith is not liable for any damages resulting from the use of non-original spare parts.
- You will find the type of your turbo coupling and the pulley design on the cover sheet of this operating manual.
- Observe → Chapter 1.2 (type designation) and → Chapter 18 (Queries, Orders places for Service Engineers and Spare Parts).
- The customer is only allowed to perform the following work:
  - Replacement of fusible pluts (item 0395 / 0260) (→ Chapter 13.4).
  - Work according to maintenance report (→ Chapter 14.3).
  - Change of operating fluid (→ Chapter 10).
  - Mounting of parts for which tightening torques are indicated (→ Chapter 3).**All remaining work may be performed by Voith staff only.**

### NOTICE

**Unauthorized changes or retrofits are not allowed to be performed on the coupling!**

**Do not retrofit accessories or equipment originating from other manufacturers!**

Any changes or conversions performed without the prior written consent of Voith Turbo will result in the loss of any warranty! Any claims will forfeit.

- Professional maintenance or repair can only be guaranteed by the manufacturer!

### SAFETY INFORMATION

If the turbo coupling is used in potentially explosive atmospheres (as per ATEX Directive), the use of original parts that have been released for use in hazardous areas is allowed only.



## 20.1 Components overview - Voith turbo coupling 154 – 650




Fig. 34

Item No.	Description	Item No.	Description
0040	Coupling hub	0190	Coupling shell
0050	Fixing bolt	0300	Outer wheel
0080	Holding disk	0320	Tolerance ring
0090	Inner wheel	0410	Delay chamber cover
0100	Riveting ring/threaded ring/clamping ring	0800	Bearing support cover
0130	Grooved ball bearing	0830	Sealing ring cover
0140	Grooved ball bearing/needle bearing	0990	Connecting cover
0160	Radial shaft sealing ring		
0170	Radial shaft sealing ring		

Table 22

Spare parts for Voith turbo coupling, → Chapter 20.2.

## 20.2 Spare parts for Voith turbo coupling 154 – 650




Fig. 35

- 1) For arrangement and quantity, see the tables → Chapter 13.4
- 2) Only for continuous operation or operating fluid 'water' (TW...).

xxxx Nonrepairable items (→ the following table)

xxxx Repair parts / wearing parts (V) (→ the following table)

<b>Item No.</b>	<b>Nonrepairable items</b>	<b>Item No.</b>	<b>Repair parts / wearing parts (V)</b>
0265	Blind screw	0050	Fixing bolt
0270	Sealing ring	0060	Locking plate/lock washer
0390	Filler plug	0070	Roll pin
0394	Blind screw	0080	Holding disk
0395	Fusible plug	0130	Grooved ball bearing (V)
0396	Sight glass	0140	Needle bearing (V)
0400	Sealing ring	0150	Snap ring
0405	Sealing ring	0155	Snap ring
0455	Nozzle screw	0165	Radial shaft sealing ring (V)
0456	Nozzle screw	0170	Radial shaft sealing ring (V)
		0175	Radial shaft sealing ring (V)
		0180	Circlip
		0320	Tolerance ring (V)
		0510	O-ring (V)
		0545	Sealing tape (V)
<b>Item No.</b>	<b>Description</b>	0610	Radial shaft sealing ring (V)
0620	Pulley	0820	O-ring (V)
0630	Socket head screw	0900	Radial shaft sealing ring (V)
0950	Bearing cover	0994	Sealing tape (V)

Table 23

# 21 Representatives - Voith Turbo GmbH & Co. KG

## Westeuropa:

**Deutschland ( VTCR ):**  
Voith Turbo GmbH & Co. KG  
Division Mining & Metals  
Voithstr. 1

**74564 CRAILSHEIM**  
GERMANY  
Tel.: +49-7951 32-409  
Fax: +49-7951 32-480  
e-mail:  
[startup.components@voith.com](mailto:startup.components@voith.com)  
[www.voith.com/fluid-couplings](http://www.voith.com/fluid-couplings)

**Service:**

Tel.: +49 7951 32-1020  
Fax: +49 7951 32-554  
e-mail:  
[vtcr-ait.service@voith.com](mailto:vtcr-ait.service@voith.com)  
Notfall Hotline (24/7):  
Tel.: +49 7951 32-599

**Belgien ( VTBV ):**  
Voith Turbo S. A. / N. V.  
Square Louisa 36  
**1150 BRÜSSEL**  
BELGIUM  
Tel.: +32-2-7626100  
Fax: +32-2-7626159  
e-mail: [voithturbo.be@voith.com](mailto:voithturbo.be@voith.com)

**Dänemark ( VTDK ):**

Voith Turbo A/S  
Egegårdsvej 5  
**4621 GADSTRUP**  
DENMARK  
Tel.: +45-46 141550  
Fax: +45-46 141551  
e-mail: [postmaster@voith.dk](mailto:postmaster@voith.dk)

**Färöer Inseln:**  
siehe Dänemark ( VTDK )

**Finnland ( Masino ):**

Masino Oy  
Kärkikuja 3  
**01740 VANTAA**  
FINLAND  
Tel.: +358-10-8345 500  
Fax: +358-10-8345 501  
e-mail: [sales@masino.fi](mailto:sales@masino.fi)

**Frankreich ( VTFV ):**  
Voith Turbo S. A. S.  
21 Boulevard du Champy-  
Richardets  
**93166 NOISY-LE-GRAND**  
**CEDEX**  
FRANCE  
Tel.: +33-1-4815 6903  
Fax: +33-1-4815 6901  
e-mail: [voithfrance@voith.com](mailto:voithfrance@voith.com)

**Griechenland:**  
siehe Deutschland ( VTCR )

**Grönland:**  
siehe Dänemark ( VTDK )

**Großbritannien ( VTGB ):**  
Voith Turbo Limited  
6, Beddington Farm Road  
**CRO 4XB CROYDON, SURREY**  
GREAT BRITAIN  
Tel.: +44-20-8667 0333  
Fax: +44-20-8667 0403  
e-mail: [Turbo.UK@voith.com](mailto:Turbo.UK@voith.com)  
Notfall Hotline (24/7):  
Tel.: +44-20-8667 0333

**Irland:**  
siehe Großbritannien ( VTGB )

**Italien ( VTIV ):**  
Voith Turbo s.r.l.  
Via G. Lambrakis 2  
**42122 REGGIO EMILIA**  
ITALY  
Tel.: +39-05-2235-6714  
Fax: +39-05-2235-6790  
e-mail: [info.voithturbo@voith.com](mailto:info.voithturbo@voith.com)

**Liechtenstein:**  
siehe Deutschland ( VTCR )

**Luxemburg:**  
siehe Belgien ( VTBV )

**Niederlande ( VTNT ):**  
Voith Turbo B.V.  
Koppelstraat 3  
**7391 AK TWELLO**  
THE NETHERLANDS  
Tel.: +31-571-2796-00  
Fax: +31-571-2764-45  
e-mail:  
[voithnederland@voith.com](mailto:voithnederland@voith.com)

**Norwegen ( VTNO ):**  
Voith Turbo AS  
Lahaugmoveien 30A  
**2013 SKJETTEN**  
NORWAY  
Tel.: +47 6384 7020  
Fax: +47 6384 7021  
e-mail:  
[info.turbo.norway@voith.com](mailto:info.turbo.norway@voith.com)

**Österreich:**  
Indukont Antriebstechnik GmbH  
Badenerstraße 40  
**2514 TRAIKIRCHEN**  
AUSTRIA  
Tel.: +43-2252-81118-22  
Fax: +43-2252-81118-99  
e-mail: [info@indukont.at](mailto:info@indukont.at)

**Portugal:**  
siehe Spanien ( VTEV )

**Schweden ( VTSN ):**  
Voith Turbo AB  
Finspångsgatan 46  
**16353 SPÅNGA-STOCKHOLM**  
SWEDEN  
Tel.: +46-8-564-755-50  
Fax: +46-8-564-755-60  
e-mail:  
[voithturbo.sweden@voith.com](mailto:voithturbo.sweden@voith.com)

**Schweiz:**  
siehe Deutschland ( VTCR )

**Spanien ( VTEV ):**  
Voith Turbo S. A.  
Avenida de Suiza 3  
P.A.L. Coslada  
**28820 COSLADA (MADRID)**  
SPAIN  
Tel.: +34-91-6707816  
Fax: +34-91-6707841  
e-mail:  
[voithturbospain@voith.com](mailto:voithturbospain@voith.com)

**Osteuropa:**

**Albanien:**  
siehe Ungarn ( VTHU )

**Bosnien-Herzegowina:**  
siehe Ungarn ( VTHU )

**Bulgarien:**  
siehe Ungarn ( VTHU )

**Estland:**  
siehe Polen ( VTPL )

**Kosovo:**  
siehe Ungarn ( VTHU )

**Kroatien:**  
siehe Ungarn ( VTHU )

**Lettland:**  
siehe Polen ( VTPL )

**Litauen:**  
siehe Polen ( VTPL )

**Mazedonien:**  
siehe Ungarn ( VTHU )

**Polen ( VTPL ):**  
Voith Turbo sp.z o.o.  
Majków Duży 74  
**97-371 WOLA**  
**KRZYSZTOPORSKA**  
POLAND  
Tel.: +48-44 646 8848  
Fax: +48-44-646 8520  
e-mail:  
[voithturbo.polska@voith.com](mailto:voithturbo.polska@voith.com)

Notfall Hotline (24/7):  
Tel.: +48-44 646 8519

**Rumänien ( VTRO ):**  
Voith Turbo S.R.L.  
Strada Barbu Vacarescu nr. 13  
etaj 3 si 4  
**020271 BUCHAREST**  
ROMANIA  
Tel.: +40-31-22 36100  
Fax: +40-31-22 36210  
e-mail:  
[voith.romania@voith.com](mailto:voith.romania@voith.com)

**Russland ( VTRU ):**  
Voith Turbo O.O.O.  
Branch Office Moskau  
Nikolo Yamskaya ul. 21/7, str. 3  
**109240 MOSKAU**  
RUSSIA  
Tel.: +7 495 915-3296 ext. 122  
Fax: +7 495 915-3816  
Mobil Herr Balanzev:  
+7 919 108 2468  
e-mail:  
[voithmoscow@Voith.com](mailto:voithmoscow@Voith.com)

Voith Turbo  
Branch Office Novokusnetsk  
( Shcherbinin, Anatoliy )  
Skorosnaya ul. 41, Liter B1  
**654025 NOVOKUSNETSK**  
Kemerovskaya oblast  
RUSSIA  
Tel./Fax: +7 3843 311 109  
Mobil: +7 9132 802 110  
e-mail: [voith22@bk.ru](mailto:voith22@bk.ru)

**Serbien:**  
siehe Ungarn ( VTHU )

**Slowakische Rep.:**  
siehe Tschechien ( VTCZ )

**Slowenien:**  
siehe Ungarn ( VTHU )

**Tschechien ( VTCZ ):**  
Voith Turbo s.r.o.  
Hvezdoslavova 1a  
**62700 BRNO**  
CZECH REPUBLIC  
Tel.: +420-543-176163  
Fax: +420-548-226051  
e-mail: [info@voith.cz](mailto:info@voith.cz)

**Ukraine ( VTUA ):**  
Voith Turbo Ltd.  
Degtyarivska Str. 25, Building 1  
**04119 KIEV**  
UKRAINE  
Tel.: +380-44-581 4760  
Fax: +380-44-581 4761  
e-mail:  
[Dmitriy.Kalinichenko@Voith.com](mailto:Dmitriy.Kalinichenko@Voith.com)

siehe auch Polen ( VTPL )

**Ungarn ( VTHU ):**  
Voith Turbo Kft.  
Felvég Útca 4  
**2051 BIATORBÁGY**  
HUNGARY  
Tel.: +36-23-312 431  
Fax: +36-23-310 441  
e-mail: [vthu@voith.com](mailto:vthu@voith.com)

**Nordamerika:**

**Kanada ( VTC ):**  
Voith Turbo Inc.  
171 Ambassador Drive, Unit 1  
**L5T 2J1 MISSISSAUGA,**  
**ONTARIO**  
CANADA  
Tel.: +1-905-670-3122  
Fax: +1-905-670-8067  
e-mail: [Info@voithusa.com](mailto:Info@voithusa.com)  
  
Notfall Hotline (24/7):  
Tel.: +1-905-738-1829

**Mexico ( VTX ):**  
Voith Turbo S.A. de C.V.  
Alabama No.34  
Col. Nápoles Delg. Benito Juarez  
**C.P. 03810 MÉXICO, D.F.**  
MÉXICO  
Tel.: +52-55-5340 6970  
Fax: +52-55-5543 2885  
e-mail: [vtx-info@voith.com](mailto:vtx-info@voith.com)

**USA ( VTI ):**  
Voith Turbo Inc.  
25 Winship Road  
**YORK, PA 17406-8419**  
UNITED STATES  
Tel.: +1-717-767 3200  
Fax: +1-717-767 3210  
e-mail:  
[VTI-Information@voith.com](mailto:VTI-Information@voith.com)  
  
Notfall Hotline (24/7):  
Tel.: +1-717-767 3200  
e-mail:  
[VTIServiceCenter@vti.com](mailto:VTIServiceCenter@vti.com)

**Süd- + Mittelamerika:**

**Brasilien ( VTPA ):**  
Voith Turbo Ltda.  
Rua Friedrich von Voith 825  
**02995-000 JARAGUÁ, SÃO PAULO - SP**  
BRAZIL  
Tel.: +55-11-3944 4393  
Fax: +55-11-3941 1447  
e-mail:  
[info.turbo-brasil@voith.com](mailto:info.turbo-brasil@voith.com)

Notfall Hotline (24/7):  
Tel.: +55-11-3944 4646

**Chile ( VTCI ):**  
Voith Turbo S. A.  
Av. Pdte.Eduardo Frei Montalva  
6115  
**8550189 SANTIAGO DE CHILE (CONCHALI)**  
CHILE  
Tel.: +56-2-944-6900  
Fax: +56-2-944-6950  
e-mail:  
[VoithTurboChile@voith.com](mailto:VoithTurboChile@voith.com)

**Ecuador:**  
siehe Kolumbien ( VTKB )

**Kolumbien ( VTKB ):**  
Voith Turbo Colombia Ltda.  
Calle 17 No. 69-26  
Centro Empresarial Montevideo  
**110931 BOGOTÁ, D.C.**  
COLOMBIA  
Tel.: +57 141-17664  
Fax: +57 141-20590  
e-mail:  
[voith.colombia@voith.com](mailto:voith.colombia@voith.com)

**Peru ( VTPE ):**  
Voith Turbo S.A.C.  
Av. Argentina 2415  
**LIMA 1**  
PERU  
Tel.: +51-1-6523014  
e-mail:  
[Lennart.Kley@Voith.com](mailto:Lennart.Kley@Voith.com)

siehe auch Brasilien ( VTPA )

**Venezuela:**  
siehe Kolumbien ( VTKB )

**Afrika:**

**Ägypten:**  
Copam Egypt  
33 El Hegaz Street,  
W. Heliopolis  
**11771 CAIRO**  
EGYPT  
Tel.: +202-22566 299  
Fax: +202-22594 757  
e-mail: [copam@datum.com.eg](mailto:copam@datum.com.eg)

**Algerien:**  
siehe Frankreich ( VTFV )

**Botswana:**  
siehe Südafrika ( VTZA )

**Elfenbeinküste:**  
siehe Frankreich ( VTFV )

**Gabun:**  
siehe Frankreich ( VTFV )

**Guinea:**  
siehe Frankreich ( VTFV )

**Lesotho:**  
siehe Südafrika ( VTZA )

**Marokko ( VTCA ):**  
Voith Turbo S.A.  
Rue Ibnou El Koutia, No. 30  
Lot Attawfiq - Quartier Oukacha  
**20250 CASABLANCA**  
MOROCCO  
Tel.: +212 522 34 04 41  
Fax: +212 522 34 04 45  
e-mail: [allal.elfassi@voith.ma](mailto:allal.elfassi@voith.ma)

**Mauretanien:**  
siehe Spanien ( VTEV )

**Mozambique:**  
siehe Südafrika ( VTZA )

**Namibia:**  
siehe Südafrika ( VTZA )

**Niger:**  
siehe Frankreich ( VTFV )

**Senegal:**  
siehe Frankreich ( VTFV )

**Südafrika ( VTZA ):**  
Voith Turbo Pty. Ltd.  
16 Saligna Street  
Hughes Business Park  
**1459 WITFIELD, BOKSBURG**  
SOUTH AFRICA  
Tel.: +27-11-418-4000  
Fax: +27-11-418-4080  
e-mail: [info.VTZA@voith.com](mailto:info.VTZA@voith.com)

Notfall Hotline (24/7):  
Tel.: +27-11-418-4060

**Swaziland:**  
siehe Südafrika ( VTZA )

**Tunesien:**  
siehe Frankreich ( VTFV )

**Zambia:**  
siehe Südafrika ( VTZA )

**Zimbabwe:**  
siehe Südafrika ( VTZA )

**Naher- +**

**Mittlerer Osten:**

**Bahrain:**

siehe Vereinigte Arabische  
Emirate ( VTAE )

**Irak:**

siehe Vereinigte Arabische  
Emirate ( VTAE )

**Iran ( VTIR ):**

Voith Turbo Iran Co., Ltd.  
1<sup>st</sup> Floor, No. 215  
East -Dastgerdi Ave.  
Modares Highway  
**19198-14813 TEHRAN**  
IRAN  
Tel.: +98-21-2292 1524  
Fax: +98-21-2292 1097  
e-mail: [voithturbo.iran@voith.ir](mailto:voithturbo.iran@voith.ir)

**Israel ( VTIL ):**

Voith Turbo Israel Ltd.  
Tzvi Bergman 17  
Segula Ind. Zone  
**49279 PETACH-TIKVA**  
ISRAEL  
Tel.: +972-3-9131 888  
Fax: +972-3-9300 092  
e-mail: [TPT.Israel@voith.com](mailto:TPT.Israel@voith.com)

**Jemen,  
Jordanien,  
Kuwait,  
Libanon,  
Oman,  
Qatar,  
Saudi Arabien,  
Syrien:**

siehe Vereinigte Arabische  
Emirate ( VTAE )

**Türkei ( VTTR ):**

Voith Turbo Güç Aktarma Tekniği  
Ltd. Şti.  
Armada İş Merkezi Eskişehir  
Yolu No: 6 A-Blok Kat: 13  
**06520 SÖĞÜTÖZÜ-ANKARA**  
TURKEY  
Tel.: +90 312 495 0044  
Fax: +90 312 495 8522  
e-mail: [voith-turkey@voith.com](mailto:voith-turkey@voith.com)

**Vereinigte Arabische Emirate  
( VTAE ):**

Voith Middle East FZE  
P.O.Box 263461  
Plot No. TP020704  
Technopark, Jebel Ali  
**DUBAI**  
UNITED ARAB EMIRATES  
Tel.: +971-4 810 4000  
Fax: +971-4 810 4090  
e-mail:  
[voith-middle-east@voith.com](mailto:voith-middle-east@voith.com)

**Australien:**

**Australien ( VTAU ):**

Voith Turbo Pty. Ltd.  
Building 2,  
1-47 Percival Road  
**2164 SMITHFIELD NSW**  
AUSTRALIA  
Tel.: +61-2-9609 9400  
Fax: +61-2-9756 4677  
e-mail: [vtausydney@voith.com](mailto:vtausydney@voith.com)  
  
Notfall Hotline (24/7):  
Tel.: +61-2-9609 9400  
e-mail:  
[vtau\\_spare\\_parts@voith.com](mailto:vtau_spare_parts@voith.com)

**Neuseeland ( VTNZ ):**

Voith Turbo NZ Pty. Ltd.  
295 Lincoln Rd.  
Waitakere City  
**0654 AUCKLAND**  
NEW ZEALAND  
Tel.: +11 64 9838 1269  
Fax: +11 64 9838 1273  
e-mail: [VTNZ@voith.com](mailto:VTNZ@voith.com)

**Südostasien:**

**Brunei:**

siehe Singapur ( VTSG )

**Bangladesh:**

siehe Singapur ( VTSG )

**Indien ( VTIP ):**

Voith Turbo Private Limited  
Transmissions and Engineering  
P.O. Industrial Estate  
**500 076 NACHARAM-  
HYDERABAD**  
INDIA  
Tel.: +91-40-2717 3561+3592  
Fax: +91-40-27171 141  
e-mail: [info@voithindia.com](mailto:info@voithindia.com)  
  
Notfall Hotline (24/7):  
Tel.: +91-99-4906 0122  
e-mail: [vtip.service@voith.com](mailto:vtip.service@voith.com)

**Indonesien ( VTID ):**

PT Voith Turbo  
Jl. T. B. Simatupang Kav. 22-26  
Talavera Office Park  
28th Fl.  
**12430 JAKARTA**  
INDONESIA  
Tel.: +62 21 7599 9848  
Fax: +62 21 7599 9846

**Malaysia:**

siehe Singapur ( VTSG )

**Myanmar:**

siehe Singapur ( VTSG )

**Philippinen:**

siehe Singapur ( VTSG )

**Singapur ( VTSG )**

Voith Turbo Pte. Ltd.  
10 Jalan Lam Huat  
Voith Building  
**737923 SINGAPORE**  
SINGAPORE  
Tel.: +65-6861 5100  
Fax: +65-6861-5052  
e-mail:  
[sales.singapore@voith.com](mailto:sales.singapore@voith.com)

**Thailand:**

siehe Singapur ( VTSG )

**Vietnam:**

siehe Singapur ( VTSG )



**Ostasien:**

**China:**

siehe Hongkong ( VTEA )

Voith Turbo Power Transmission  
(Shanghai) Co., Ltd. ( VTCT )  
Beijing Branch  
18 Floor, Tower F, Phoenix Place  
5A Shuguang Xili, Chaoyang  
District

**100028 BEIJING**

P.R. CHINA

Tel.: +86-10-5665 3388

Fax: +86-10-5665 3333

e-mail:

[VT\\_Industry\\_China@Voith.com](mailto:VT_Industry_China@Voith.com)

Voith Turbo Power Transmission  
(Shanghai) Co. Ltd. ( VTCN )  
Representative Office Shanghai  
No. 265, Hua Jin Road  
Xinzhuang Industry Park

**201108 SHANGHAI**

P.R. CHINA

Tel.: +86-21-644 286 86

Fax: +86-21-644 286 10

e-mail: [VTCN@Voith.com](mailto:VTCN@Voith.com)

Service Center ( VTCT ):

Voith Turbo Power Transmission  
(Shanghai) Co. Ltd.

Taiyuan Branch

No. 36 Workshop, TISCO,

No. 73, Gangyuan Road

**030008 TAIYUAN, SHANXI**

P.R. CHINA

Tel.: +86 351 526 8890

Fax: +86 351 526 8891

e-mail:

[VT\\_Industry\\_China@Voith.com](mailto:VT_Industry_China@Voith.com)

Notfall Hotline (24/7):

Tel.: +86 21 4087 688

e-mail:

[Hongjun.Wang@voith.com](mailto:Hongjun.Wang@voith.com)

**Hongkong ( VTEA ):**

Voith Turbo Ltd.

908, Guardforce Centre,

3 Hok Yuen Street East,

**HUNGHOM, KOWLOON**

HONG KONG

Tel.: +85-2-2774 4083

Fax: +85-2-2362 5676

e-mail: [voith@voith.com.hk](mailto:voith@voith.com.hk)

**Japan ( VTFC ):**

Voith Turbo Co., Ltd.

9F, Sumitomo Seimei Kawasaki Bldg.

11-27 Higashida-chou, Kawasaki-Ku,

Kawasaki-Shi,

**210-0005 KANAGAWA**

JAPAN

Tel.: +81-44 246 0555

Fax: +81-44 246 0660

e-mail: [Satoshi.Masuda@Voith.com](mailto:Satoshi.Masuda@Voith.com)

**Korea ( VTKV ):**

Voith Turbo Co., Ltd.

Room No. 1717, Golden Tower

Officetel 191

Chungjung-Ro 2-Ka

Seodaemoon-Ku

**120-722 SEOUL**

SOUTH KOREA

Tel.: +82-2-365 0131

Fax: +82-2-365 0130

e-mail: [sun.lee@voith.com](mailto:sun.lee@voith.com)

**Macau:**

siehe Hongkong ( VTEA )

**Mongolei ( VTA-MON ):**

Voith Turbo GmbH & Co. KG

2nd Floor Serkh Bogd Co. Ltd.

Office Building United Nations

Street 4, Khoroo Chingeltei District

**ULAANBAATAR**

MONGOLIA

Tel.: +976 7010 8869

e-mail: [Daniel.Bold@Voith.com](mailto:Daniel.Bold@Voith.com)

**Taiwan ( VTTI ):**

Voith Turbo Co. Ltd.

Taiwan Branch

No. 3 Taitang Road,

Xiaogang District.

**81246 KAOHSIUNG**

TAIWAN, R.O.C.

Tel.: +886-7-806 1806

Fax: +886-7-806 1515

e-mail: [sue.ou@voith.com](mailto:sue.ou@voith.com)

## 22 Index

### A

Accident, What to do in case of an accident	28
Alignment	51
Alignment tolerances	51
Ambient temperature	26
As delivered condition	33

### B

Bearing lubrication	73
Bearings	73
Belt pull, permissible	48
Belt tension	48
Blocking	31
BTM	96
BTS	94
BTS-Ex	95

### C

Catch pan	27
Check report	78
Commissioning	65
Commissioning report	80
Components overview	98
Constructional examples	10
Coupling temperature	30

### D

Dangers	21
Data, additional	13
Declaration of incorporation	17, 18
Direction of rotation	67
Disassembly	83
Disposal	87
Draining	62
Horizontal position with delay chamber	63
Horizontal position without delay chamber	63
Vertical position	64

### E

Electrical components	25
Electrical devices	26
Fastening screw	16

### F

Filling	
Horizontal position	58
Filling	
Vertical position	60
Filling the turbo coupling	58
Fire hazard	27
Fire point	53
Fixing bolt	46
Flash point	53
Function	7
Fusible plugs	26, 30, 33, 74

### H

Hazard class	21
--------------	----

### I

Information as to dangerous situations	23
Installation and alignment	41, 68, 70, 77, 83, 88
Intended use	22

### K

Keys	43
------	----

### L

Level check	61
Horizontal position	61
Vertical position	62
Level check device	60
Lifting	34
Lifting appliances	34

### M

Maintenance	69
Bearings	73
Belts	74
Fusible plugs	74
Maintenance report	82
Maintenance schedule	70
Malfunction - remedy	88
Manufacturer's declaration	17, 18
Methane content, Check of methane content	27
Mineral oils	53

Monitoring devices	31, 92
BTM	96
BTS	94
BTS-Ex	95
MTS	93
Mounting	44
Mounting device	47
Mounting of belts	48
MTS	93
Multi-motor drive	67

**N**

Noise	24
-------	----

**O**

Oil list	54
Operating fluid	29
Operating fluids	33, 52
Proposed operating fluids	54
Requirements	53, 55
water	56
Operation	68, 77, 83
Order	91
Ordering a service engineer	91
Outside cleaning	72
Overload	26, 31

**P**

Packaging	39
Pour point	53
Power transmission	28
Preparation	42, 83
Preservation	39
Product monitoring	32
Protective cover	24, 65, 72
Protective hood	65
Pulley without bearings	48

**Q**

Qualification	32
Queries	91

**R**

Radial force, permissible	48
Re-lubrication	73
Remaining risks	28
Removal device	86
Repair	97
Replacement of bearings	73
Report / Protocol	78, 80, 82
Representatives	101

**S**

Safety	21
Safety information	21
Scope of supply	33
Sealing material for an operating temperature above 100 °C	53
Selection and qualification of staff	32
Serial No.	91
Servicing, Maintenance	69
Sound pressure level	24
Spanner wrench	84
Spare parts	19
Spare parts for Voith turbo coupling	99
Spare parts information	97
Spare parts orders	91
Standstill	66
Star / delta connection	67
Starting characteristic	29
Storage	33, 39
Structural modifications	23
Switching off in case of turbo coupling overload	31
Symbols	22

**T**

Technical data	12
Temperature monitoring	12, 92
Tightening torques	14, 15, 16
Tools	41
Transport	33
Type designation	9

**U**

Unintended use	23
----------------	----

**W**

Warming up	24, 29
What to do in case of accidents	28
Working on the turbo coupling	23

Voith Turbo GmbH & Co. KG  
Division Mining & Metals  
Voithstr. 1  
74564 Crailsheim, GERMANY  
Tel. + 49 7951 32 409  
Fax + 49 7951 32 480  
[startup.components@voith.com](mailto:startup.components@voith.com)  
[www.voith.com/fluid-couplings](http://www.voith.com/fluid-couplings)

**VOITH**  
Engineered Reliability